

### S5-LAN++



Art.Nr. 9359-LAN



documentation of version 1.x/2.x/3.x



## 1 Description

The S5-LAN++ module connects the computer over network with a S5-PLC. It includes a multiplexer for the S5-PLC, so you would be able for e.g. to read or write data with a visualization or production data acquisition and make parallel program-changes.

**Attention:** Please note, that the reaction time of the PLC will be increased, because now are running several communications parallel and they must be all processed with the PLC.

If the computer is connected direct to the module or over WLAN or over a VPN-connection, this is equal to the module. It is only important, that the connection is not broken or not to slow.

Before the use of a VPN-connection, you can make following test. Build-up the VPN-connection and send a ping to one client in this network. For timings of maximum 400ms you can be sure, that the communication to the module and connected PLC should be OK.

With version V1.20 and newer the module transfers in the AS511-protocol an identifier that it the conversation partner is a S5-LAN++-module. This information can by the communication-driver IP-S5-LAN-link be recognized and evaluated.

With the S5-LAN++-module you are capable to build up a coupling from a S7-PLC with Ethernet-CP (integrated or as a supplementary module) to a S5-PLC. In this case you will use the Siemens-function "PUT/GET". You configure this connection in your PLC, but now the IP-address of the S5-LAN++ is the IP-address of the configured partner.

You can find a documentation and sample project for "PUT/GET" in the hotline-section of the Siemens website, click here to reach it.

## 2 System requirements

## 2.1 Operating System(s)

Windows

- 10
- 8
- 7
- Vista
- XP
- ME/NT/2000

## 2.2 Software

PLC - programming software (e.g. PG2000, Step  $\ensuremath{\mathbb{C}}$  5, S5 for windows, WinCC) PLC - VCOM Software

### 2.3 Hardware

Networkcard 10/100MBit 24V power supply (Phoenixbush or TTY-Interface)



### 2.4 Supported controls

- S5-90U with external 24V-supply
- S5-95U with external 24V-supply
- S5-100U with external 24V-supply
- S5-115U
- S5-135U
- S5-155U
- Sinumerik 810 / 880 (only DB-access read/write)
- COMCON 110 from Berthel

# 2.5 Possible problems while commissioning of the module

Module is not found in the S5-LAN-Manager though a network connection Module supplied with voltage, is the large green LED on/flashing?

Switch of the firewall in your PC and search again. This could block the communication to the module.

No PLC-communication possible?

Module supplied with voltage? Is the large green LED flashing (PLC not recognized/found), please checking the wiring/current-loop-sources

Is the PLCVCom started? Is PLCVCom connected with the module? Step5-Software reports system-error 0334h

Was the S5-patch for the module and PLCVCom installed? Is used COM-port a real COM-port (virtual COM-ports (USB-RS232-converter, PC-cards) are not recognized and used directly from Step5)?

## 3 Connecting options

#### S5-LAN++ module direct connected with the PC.



S5-LAN++ connected with the PC over a Switch or Hub.





#### S5-LAN++ connection possibilities with CrossLink-cable



## 4 Installation

### 4.1 Hardware

The S5-LAN + + module is connected directly to the PLC. About the network connection of the module, the PLC can be connected as follows:

#### S5-LAN + + to switch / hub

Here, the network cable is plugged from the S5-LAN + + module to the switch / hub. If you use a crosslink cable, plug this cable to the uplink port on the switch / hub. Use a switch with auto-negotiating function, so you can plug the network cable into a free port on the switch.

#### S5-LAN++ to PC

In this variant, you must use a crosslink cable. This plug with one end into the module and the other end into the network card.

The PLC provides the module with voltage. Alternatively, the module can be also connected to an external supply 24V/DC (if the PLC has no 24V/DC eg AG and AG-95U-100U).

### 4.2 Software

To establish a communication with the PLC, please install the PLC - VCOM software as described in the chapter "PLC-VCOM Installation ".

In addition you need programming software (eg PG2000, Step@5, S5 for Windows, WinCC) to work with the PLC.



# 4.2.1 Installation and usage of S5-LAN++-module under Win98

To work with the S5-LAN++-module under Win98, you need following software tool:

• PLCVCom - virtual COM-port

The installation of the PLC-VCOM-software is explained in section "PLC-VCOM Installation".

#### **Attention !**

Please note that the generated virtual COM-port is between COM1 to COM4. COM-ports higher than COM4 are not supported by the Step5-software!

Before starting the installation, make sure to stop any possible running S5-software, otherwise the driver could not be installed.

If you have installed the PLCVCom on your PC, proceed as follows:

• Open the PLCVCom and click the button "Configure"

III PLC-VCom	
Configuration	Info
State MPI-USB not connected	Configure
virtual Port COM3 Program Exit Language	 Help Minimize

Activate "Input manually"



|--|

Name	LAN - Type	IP-Add	ress	MAC-Address	Version	Serial number	Port	Net
address:	· ·		FF:FF:FF:	FF:FF:FF				Search
e network- rd	0:PPP Adapter.		🔽 locut	manuallu	 □ serielle	Pausanzaitan		Help
N-Type:	S7/MPI-LAN	•	I <b>∙</b> Input	manually	j senene	rausenzeiten		
			no Ne	etwork Lation in Dawing Man				OK
			E BEC1	1000 In Device-Man 1000 IT No bind t	ager o Network Cer	d		Cance

• As soon as you have selected now as LAN-Type "S5-LAN++" a new controll-button "MSDOS-Box access" is visible. Please activate this also. Now enter the IP-address of the S5-LAN-module under "IP address" and with a click on "OK" the configuration would be acceded.

Name		LAN - Type	IP-Address	MAC-Address	Version	Serial number	Port	Net
								_
address: e network:		192 . 168 . 1	. 89 F	F:FF:FF:FF:FF:FF				Search
ard 	- <u>1</u> 0.			Input manually	 □ serielle	Pausenzeiten		Help
AN-Type:	S!	5-LAN		MSDOS-Box access				04
DO DANK	10	1010		no Network				UN

Now the virtual COM-port is set and activated, so you can go with your Step5-software via COM1 ... COM4 (depending on which COM port was selected for the virtual COM-port) ONLINE.

# 4.2.2 Installation of the Step5 $\bigcirc$ addition driver for PG-USB/S5-LAN + + / USB-RS232-converter

In order to make the PLC-VCOM furnished virtual COM interface available for Siemens Step © 5 in the DOS box, must be installed this addition driver.



TRAEGER.DE Söllnerstr. 9 92637 Weiden info@traeger.de +49 (0)961 48 23 0 0

**! Important !** PLC-VCOM must be installed before this Step © 5 addition driver. The installation of the PLC-VCOM software is explained in the chapter "PLC-VCOM installation".

Before you start the installation, make sure to stop any possible still running S5 original software, otherwise the driver can not be installed.

- 1. Please download from the you known web-site the "S5-patch" and extract the file on your PC.
- 2. Now start the application "S5USB.exe" from the previously extracted folder

	Welches Gerät verwenden sie ?	
Gerät	C PG-USB	
	• S5-LAN	

3. Device selection Now select the type of device. Select "S5-LAN + + / PG-USB-cable / USB-RS232-converter" and confirm with "OK".

V1.22	X
Dieser Treiber stellt der S5-Driginal-Software das S5-LAN-Kabel	Installieren
als COM-Schnittstelle unter Windows XP/2000 zur Verfügung	De-Installieren
Beenden Sie die eventuell noch laufende S5-Original-Software !	Ende
	Hilfe

4.In the next dialog, start the installation by clicking on the "Install" button. The installation wizard will now copy the required data. Please wait a moment.

5. Specify the folder where the software S5 is installed. Please wait while the installation routine searches for the S5 software version.

6. Next, select the COM port and click "OK".

- 7. Soon as the installation is complete, you press "Finish".
- 8. When the "Install" button is disabled (gray font), the installation is complete.

9. Now close the wizard with "Finish".

With "Uninstall" you delete the already installed drivers.

If the COM port of the PLC-VCOM is changed afterwards, the Step5 © drivers must be reinstalled! **Attention!** 

#### For the Step5 Siemens software

For the Step5 Siemens software the COM port must be are between COM1 and COM4. Check and correct it if necessary.

To do this go into the Control Panel, then into system, select the hardware tab and click the button Device Manager. In the Device Manager under "Ports (COM & LPT)" appears the virtual COM port "USB Serial Port (COMx)".

Right click on the USB Serial Port and then select "Properties" in the context menu. There you click on the tab "Port Settings". In the next dialog you select the button "Advanced" and in the following dialog the COM port can be selected.



## 5 Control elements

## 5.1 LEDs and reset



The network LED's (10MB left / 100MB	right) behave the same
LED off:	connected to no network.
LED on:	network connected (LINK).
LED blinking:	communication over the network.
State of S5 communication (green-rou	nd LED)
LED off:	device is off or in boot state.
LED on:	module reports AG online
Reset button for factory settings	
The best solution to reset of the hardware c	onfiguration you trigger with a straight bent paper clip.

Push the paper clip into the hole and after 2 seconds the S5 communication LED starts to flicker. Now you can remove the paper clip. The module makes a reset and starts with the configuration "DHCP / AutoIP" and "auto Subnet". When the LED shines the module is ready for operation again.

## 6 Implementing

Connect your module as described in the chapter "Hardware installation " to the PLC and to the programming device or to your computer.

If you want to respond to a PLC via the module you have to comply the requirements as descript in the chapter "system requirements". In addition, please make sure that the module is properly connected

## 6.1 Initial configuration

1. Start the S5-LAN Manager from either the start menu or from the PLC-VCOM menu under "Configuration"  $\Rightarrow$  "S5LAN"

	Тур	IP (aktuell)	IP (im Gerät)	MAC-Adresse	Version	Status
Fest KM	S5-LAN++	192.168.1.54	192.168.1.54	00-20-4A-BC-F6-85	1.18	running
Schrank EG Fest BE	S5-LAN S5-LAN++	192.168.1.109 192.168.1.83	192.168.1.109 192.168.1.83	00-20-4A-A9-FB-75 00-20-4A-8D-7D-4E	0.72 1.18	running running
		100				>
Firmwareinfo						
Dateiname:						
1						
Status: [						
Status: [ (			Suche im lokalen	1 Netz Fir	mwaredate	i laden
Status: (			Suche im lokalen Suche bestimmte A	n Netz Fir Adresse F	mwaredate	i laden
Status: (			Suche im lokalen Suche bestimmte / 5-Gateway Verbind	n Netz Fir Adresse F Jungen E	mwaredate irmware se Einstellunge	i laden

- 2. Click on "Local searches" to display the modules that are available in your network.
- 3. Click on a found module, to select it and mark it blue.

4. To change the settings of the S5-LAN + + module, click on "Settings".

Gerätename:	Test KM	
S5-PG-Port:	10010	
S7/S5-Server-Port	102	
IP-Adresse	IP 🔲 auto Subnet	
IP-Adresse	IP auto Subnet	
IP-Adresse DHCP /Auto IP-Adresse: Subnet-Maske:	IP auto Subnet 192 . 168 . 1 . 54 255 . 255 . 255 . 0	ĸ

5. If desired enter here a name for your S5-LAN + + to make it easier to recognizable the PLC-VCOM. In addition, please enter an IP address and a subnet mask, if your network has running a DHCP server. 6. to save the settings, click "OK"



TRAEGER.DE Söllnerstr. 9 . 92637 Weiden . info@traeger.de . +49 (0)961 48 23 0 0

More information about the S5-LAN Manager, see the chapter "configuration"

## 6.2 Using the PLC-VCOM

(The PLC-VCOM is only needed if your module is not connected via the 9 pin COM port to the computer. For products with USB, Ethernet connection, etc., the PLC-VCOM is required)

1. Start the PLC - VCOM application (If it has not already started yet).

2. Click in the main window of the PLC-VCOM, in the status area "configure". The configuration wizard will start.

3. It lists all the found modules / cables and the additional information's such as IP address and MAC address of the module.

4. Choose the desired MPI cable and click "OK" to go on.

5. If the connection is established the chosen cable is shown in the section state and on the left side you can see the status connected.

6. It also displays, the PLC-VCOM the IP address for the module and the IP address of the computer which is connected to the module.

If you have any promlems with the use of PLC-VCOM software, go to the chapter PLC – VCOM and look there for operating instructions.

# 6.3 Programming software to use with direct access

After you have adjusted and connected the PLC-VCOM or the programming adapter to the COM-port on your computer, you will be able to connect with your programming software to the PLC and work with it.

How you have to adjust your programming software is described in the following points:

### 6.3.1 S7-TCP/IP to S5-LAN++

The S5-LAN++ behaves like an CP 343-1 or like a HMI-ProfiNet-connection. Therefor use the same configuration like a connection wih Simatic S7 300/400 over TCP/IP.



#### For S5/S7 enter server-port 102 in the S5-LAN++!

In default settings this port is already on 102. Choose for the communications driver in the WinCC-flexible the SIMATIC S7 300/400 like in the picture shown. In the PLC you have to enter the IP-address of the S5-LAN++. Put the type on"IP". Rack- and slotnumber arn't significant for operation with the S5-LAN++. Just enter the standards: Rack 0, Slot 2.

Pay attention, that the settings of the access point (S7ONLINE) are correct. Settings can be done in the control panel "PD/PC-interface settings". Take care, that you choose an adapter which supports TCP/IP.

20MI INC. ISTED 71 STCD 8D S M44	ulada u
enutzte Schnittstellengarametrierung:	(
CP/IP -> NdisWanlp	Eigenschalten
CP/IP -> NdisWanip	Diagnose
CP/IP -> NdisWanIp  Keine>  ISO Ind. Ethernet -> VMware Accel TCP/IP -> NdisWanIp	Ligenschaften
CP/IP -> NdisWanIp Konstant SO Ind. Ethernet -> VMware Accel TCP/IP -> NdisWanIp TCP/IP -> VMware Accelerated Atracelerated	Ligenschaften Diagnose Kopieren Löschen

#### Important! Important!

The addressing

The conversion from S5-Float (KG-format) to S7-Float (IEEE 754) happens automatically in each direction. Therefor use a variable type with IEEE 754.

The addressing for flag, imputs, outputs, timer and counter are indentical for S5 and S7. However, there are some difference between the datablocks. The addressing of the datablocks adapted to the S7. Example:

DB10 DW 10 (S5) is addressed with DB10.DBW20 (S7). Thats because the S7 addressed principle bytes. If you want to read one single byte e.g. DB10. DL4 (S5) you have to address DB10.DBB8. There are: even byteaddress = DL, odd address = DR in the DB of the S5.

Here some address-examples



Simatic S5	Simatic S7	Format
MB 11	MB 11	Byte
MW 20	MW 20	Word
DB10 DW 9	DB10 DBW 18	Word
DB10 DW 60	DB10 DBW 120	Word
DB10 DL 3	DB10 DBB 6	Byte
DB10 DR 3	DB10 DBB 7	Byte
DB10 DD 25	DB10 DD 50	DWord
DB10 DD 35	DB10 DD 70	Real

#### How to address a DX (advanced DB e.g. 135)?

If a DX have to addressed in a e.g. CPU 135, the rule is: DB-number 1-255 = DB, DB-number > 255 = DX

### 6.3.2 PG2000 für S5 (V5.10)

1.Start the PG 2000 software by using the desktop link or by using the application entry in the start menu.

	Options	₩indow	⊆ontroller	Help			
Ī	✓ Symbol	ols					
	⊻jew a	Il symbols					
	View 3	ibsolute op	perands				
	View s	ymbol con	ment				
	Symbol and absolute operands						
	✓ use re	ference fi	e				
	Select	reference	file				
	Printer	r configura	ation				
	Sy <u>m</u> bo	ols file		•			
	Eoote	r file		•			
	⊆onfig	urations					
	Archiv	er					
	Addre	sses s-flaç	ps				
	Interf	aces					
	PG pa	th					
	Langu	age					
	Moder	n config.					

2. Choose from menu "View"  $\Rightarrow$  "S5 155U-90 ..." In the menu "Options" click "Interfaces".

TRAEGER.DE Söllnerstr. 9 \_ 92637 Weiden \_ info@traeger.de \_ +49 (0)961 48 23 0 0



Interface	uð þer a kuð þer a kuð 19. se sa se sa sa s				
Interface	-				
PLC-Inter	ace:	M2 -			
Timeout (:	>= 550); 250	00	ms		
Retries:	3				
Timeout between D	ata 220	)	ms		
STL not executed:	250	00	ms		
Save file-by-file	Save file-by-file				
Show Properties at	Load-time 🔽				
Bus grip					
🔽 Grip always only	🔽 Grip always only one block from PLC				
🔲 stat.PLC access	FB:nam	as 🔽 Betin	ío		
Check COM-Por	Check COM-Ports				
Baudrate: vown Address 0					
PC-MPI 187.5kBau -					
,					
Connect over follow	ing Network-	Adapter:			
Intel 21143-basierter PCI-Fast Ethernetadapter (5 💌					
	0.0.	0.0			
ОК	Cancel	Help	,		

3. A dialog appears. In the section "Interface" you can configure the "PLC - Interface" (COM - Port).4. Set in the section "Bus grip" the tick "Grip allways only one block from PLC", "FB-names", "Bst. Info" and "check "COM-Ports"

5. Save your configuration by pressing "OK".

<u>PLC</u>
<u>F</u> ile
<u>I</u> eleService
S5 - Simulator
Programmer
<u>C</u> ancel

6. Now the software is ready to establish a connection to the PLC. Click the symbol "Open" and afterwards press "PLC". Alternative you can click "File" - "Open" - "PLC".

TRAEGER.DE Söllnerstr. 9 . 92637 Weiden . info@traeger.de . +49 (0)961 48 23 0 0

		DB SDB FB I	C OB SFB SFC VA	тк v Σ»		
Mark	Baustein	Größe	Adresse	Bib-Nr	Bausteinname	
	OB 001	128 W				zyklischer Bau:
	SFC 000	90 VV			SET_CLK	Uhrzeit setzen
	SFC 001	90 W			READ_CLK	Uhrzeit lesen
	SFC 006	126 W			RD_SINFO	Startinformation
	SFC 020	92 W			BLKMOV	Variable kopier
	SFC 021	92 W			FILL	Variablenspeic
	SFC 022	96 VV			CREAT_DB	Datenbaustein
	SFC 023	90 VV			DEL_DB	Löschen eines
	SFC 024	94 W			TEST_DB	Testen eines D
	SFC 036	96 VV			MSK_FLT	Synchronfehlei
	SFC 037	96 VV			DMSK_FLT	Synchronfehler
	SFC 038	96 VV			READ_ERR	Ereignisstatusr
	SFC 039	92 W			DIS_IRT	Bearbeitung ne
	SFC 040	92 W			EN_IRT	Bearbeitung ne
	SFC 041	88 W			DIS_AIRT	Bearbeitung vo
	SFC 042	88 VV			EN_AIRT	Bearbeitung vo
	SFC 043	86 VV			RE_TRIGR	Zykluszeitüber
	SFC 046	86 VV			STP	CPU in Betriebs
	SFC 047	88 W			WAIT	Verarbeitung v

The connection between PG 2000 and the PLC is now established. A new window appears. Now you can edit the blocks in the PLC.

### 6.3.3 SIMATIC Step<sup>©</sup> 5 Manager

1. Start your SIMATIC Step  $\ensuremath{\mathbb{C}}$  5 Manager by using the desktop link or the application entry in the start menu.

Dates	Editor	Test	RG	Verwaltung	Dokumentati
Baus Bos-	ekt 2 teine > Verzeichni:	• •		Laden	

2. in the "File" menu , in submenu "project" you can the "Setting" dialog open.

3. In the tab "AG" configure the used PLC interface (example: "AS511"). Below that, you can set the COM port (example: "COM3").

5 Optionen	6 EPROM	7 AWL-Batch	
AG	2 Bausteine	3 Symbolik	4 Dokumentation
etriebsart:	Offline	Aenderbarkeit:	
6-Typ:			
chnittstelle: arameter:	AS511 Com3:		
fadname		1	
-> im Systemka fadoption:	talog Nein		
	auch in Businsmid	atei aktualisieren	<pre></pre>
] Aenderungen	auch in rrogrammud	rees direadans ser en	

r	-0. (01L1 3 (05_	_outen diominier a. Int-		
5 Optionen	6 EPROM	7 AWL-Batch		
1 AG	2 Bausteine	3 Symbolik	4 Dokumentation	
no the	no 100 0 010-600	10113 01 0 750		
Schnittstelle: Parameter: Pfadname	AS511 Com3:	1		
Schnittstelle: Parameter: Pfadname Pfaddatei -> im Systemka Pfadoption:	AS511 COM3: [NONAMEAP.INI] talog Nein	]	/ Nistania - 54	
Schnittstelle: Parameter: Pfadname Pfaddatei -> im Systemka Pfadoption: [] Aenderungen	AS511 COM3: [NONAMEAP.INI] talog Nein Nein auch in Programmda	] atei aktualisieren	<pre>&lt; Historie F1 &lt; Editieren F2 &lt; Waehlen F3 &lt; Naechste F4 &lt; Info F7</pre>	>>>>>

4. with "F3" change, the "operating mode" to "online". The window should display the "AG-type"5. The connection with the PLC is successfully established when the "operating mode" changes to "Online."

### 6.3.4 Windows Control Center (WinCC) (v6.0)

- 1. Start WinCC by using the desktop link or the program entry in the start menu.
- 2. Choose "New" in the menu "File" or click on the white ("letter") symbol to start a new project.

WinCC Explorer
Create a New Project
Single-User Project
S Multi-User Project
C Client Project
C Open an Existing Project
Cancel

3. The next dialog offers you several project types "Single - User Project", "Multi - User Project" and "Client Project". The next steps are describing the "Single - User Project".

TDAC

TRAEGER.De Söllnerstr. 9 . 92637 Weiden . info@traeger.de . +49 (0)961 48 23 0 0



Project Name:	Project Path c:\projekt Eolder:	Cigate Cancel
New Subfolder: Projekt	I.I.I	Help
You can use this dialog box to create a new WinCC project.	Drive:	

4. OK" leads you to a new dialog. Type in the "Project Name" and the "Subfolder" of the "Project Path" With "Create" the chosen configuration is confirmed.

If you want to use one of the other options, please read this further in the manual of the WinCC software.

5. Please wait until the project is created. Afterward the project content is shown in the left part of the main window.

🥙 WinCCExplorer - H	:\PROGRAMME\SIEMEN				
File Edit View Tools	Help				
] 🗅 📽   🔳 🕨   🐰	1 <b>1</b> 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1				
Projekt ∰ Computer ∰ Tag Managemen ∰ Internal tag ∰ SIMATIC S7	nt js 7 PROTOCOL SUITE				
MPI PROI System Parameter					
I Slot I Find TCP/ Paste					
⊞ PROI ⊞ Indu	Properties				

6. For a proper working communication with the PLC there must be defined how the software has to communicate with the PLC Therefore right click on "Tag Management" to open the context menu. Choose "Add New Driver ...".



7. In the dialog "Add new driver" select the driver which fits to your PLC For a S5 PLC, you can choose the file SIMATIC S5 Programmers Port AS511.chn. If you are using a different PLC please inform yourself which driver fits with your PLC.

It is important that the chosen driver fits with the PLC otherwise the connection cannot be established.





8. In the explorer you should see into the variable manager the branch "SIMATIC S5 PROGRAMMERS PORT".

Expand the branch and the protocols for several connections will appear Right click on the desired connection "S5-AS511". A context menu opens. Click on "New Connection…".

9. Now you are able to type in the name of the connection. With a click on "Configuration" a new dialog will appear. Set up the station address of the PLC (in this example "3").

10. Confirm with "OK" until you are back to the main window.

11. Now you can with react the communication and with react this end it again.

### 6.3.5 Direct communication with WinCC 6.0

This communication uses the H1-ISO-on TCP or RFC1006 protocol. It is used in Siemens' S5 world to communicate over Ethernet with the CP 1430 TCP. TSAP and SSAP must be specified. S5-LAN ++ accepts any name for SSAP or TSAP.

If you want to use this protocol, enter the module as S5 server port 102. The configuration of the S5-LAN ++ is explained in a short version. To configure your S5-LAN ++ module, please read the chapter "Configuration".

1. First, start the S5-LAN Manager via the corresponding link in the Start menu.

2. Press the "Search on local network" button and select the S5-LAN ++ module to be used for communication with WinCC.

3. Click on the "Settings" button to access the settings dialog. There you configure the "S5 server port" to "102".

4. Confirm the entry with "OK" and exit the program.

5. In addition, you must set the PG / PC interface to set up an appropriate assignment point. Go to the system control and click "Set PG / PC interface".

6. Under "Access point of the application", look for "TCP\_IP:". If there is no entry, choose "<Add / Delete>".

TRAEGER.DE SO	öllnerstr. 9 <mark>-</mark> 926	37 Weiden	info@traeger.de	+49 (0)961	48 23 0 0
---------------	---------------------------------	-----------	-----------------	------------	-----------



7. This dialog allows you to add a new access point. Give the new access point the name "TCP\_IP:" and any description (for example, "WinCC S5-LAN ++ (TCP / IP)"). Click "Add" and then "Close" the dialog.

PG/PC-Schnittstelle einstellen	x
Zugriffsweg Step 7 Projektierung	
Zugangspunkt der Applikation:	
TCP_IP:> TCP/IP -> Intel 21143-basiert	ter
<pre><hinzufügen löschen=""> CP_H1_1: CP_L2_1: FWL_LOAD MPI (WinCC)&gt; PC Adapter(MPI) S70NUNE (STEP 7)&gt; TCP/IP -&gt; Intel </hinzufügen></pre>	el 21143-basierter
TCP IP: -> TCP/IP -> Intel 21143-basiert	er
PC Adapter(Auto)	Kopieren
PC Adapter(PROFIBUS)	Löschen
(Parametrierung Ihrer NDIS-CPs mit TCP/IP Protokoll (RFC-1006)) Schnittstellen	
Hinzufügen/Entfernen:	<u>A</u> uswählen
	obrechen Hilfe

8. Select the network card to be used and select "TCP\_IP:  $\Rightarrow$  TCP / IP  $\Rightarrow$  XXX" under "Access point of the application", where "XXX" stands for the network card used. Save the setting with "OK".

9. Then start WinCC 6.0. Create a new one or open an existing project.

10. In Explorer (left half of the program) you can see various project contents. Including the "variable budget". Click on the "Variable Budget" with the right mouse button and select "Add new driver ..." from the context menu.

11. Select the "SIMATIC S5 Ethernet Layer 4.CHN" file as the communication driver. With "Open" you

TRAEGER DE

TRAEGER.DE Söllnerstr. 9 . 92637 Weiden . info@traeger.de . +49 (0)961 48 23 0 0



return to the program and you can now see a change in the "variable budget".

<u>?</u> ×
- 🖬 📩 🚽
<ul> <li>SIMATIC S5 Ethernet TF.CHN</li> <li>SIMATIC S5 Profibus FDL.chn</li> <li>SIMATIC S5 Programmers Port A</li> <li>SIMATIC S5 Serial 3964R.CHN</li> <li>SIMATIC S7 Protocol Suite.chn</li> <li>SIMATIC TI Ethernet Layer 4.CH</li> </ul>
4 Öjfnen

12. Open the new branch "SIMATIC S5 ETHERNET LAYER 4" and right-click "S5 transport (TCP / IP)". In the context menu, select "New Connection ...".

IP-Adresse 192.16	8.1.56
READ-Funktion	
Fetch <u>Aktiv</u> , Auftragstyp v	von Partner ist READ-PASSIV
C Fetch Passiv, Auftragstyp	von Partner ist WRITE-AKTIV
Eigener TSAP DontCare	Hex 44.6F.6E.74.43.61.72.65
Eremder TSAP DontCare	Hex 44.6F.6E.74.43.61.72.65
WRITE-Funktion, Auftragstyp	von Partner ist WRITE-PASSIV
Eigener TSAP DontCare	Hex 44.6F.6E.74.43.61.72.65
Fremder TSAP DontCare	Hex 44.6F.6E.74.43.61.72.65
Geben Sie die IP-Adresse des	Koppelpartners an

13. In the Properties dialog, type a name (for example, "S5-LAN") and use the "Properties" button to tell the connection the "IP address" of the S5 LAN. 14. In the "READ function" area, activate "Fetch Atkiv" and assign the "TSAP:" and "Foreign TSAP:" properties as in the lower section. Confirm the connection parameters with "OK".

15. Back in the main window of the application you should see a new connection in the branch "S5-Transport (TCP / IP)" of "SIMATIC S5 ETHERNET LAYER 4". The settings for a direct communication with WinCC have been completed.

# 6.3.6 Windows Control Center flexible 2004 (WinCC flexibel) (v5.2.0.0)

1. Start the WinCC flexibel 2004 software by using the desktop link or the program entry in the start menu.



TRAEGER.De Söllnerstr. 9 . 92637 Weiden . info@traeger.de . +49 (0)961 48 23 0 0

2. At first click on "Create an empty project" in the "Start page".



3. In the "Device selection" mark the used operator panel (example: "TP 170A") confirm with "OK".



4. After the project has been created right click in the project window on "Connections" of the sub menu "Communication". In the context menu click on "Add Connection".

5. Right in the main window appears the new tab "Connections" where you are different settings options. Important for the connection are:  $\Rightarrow$  the communication driver (set up which PLC you are using (eg: "SIMATIC S5 AS511")

 $\Rightarrow$  select the used "CPU - type" (eg "S5 95U")

 $\Rightarrow$  configure the interface parameters in the section "terminal"

(eg: baud rate "9600", Parity", even", Data bits "8", Stop bits "1").

			· · · · · · · · · · · · · · · · · · ·	
			CONNECTIO	NS
Name	Communication driver Online	e Comment		
Connection_1	SIMATIC 57 300/400 • On	*		
	Alen Bradley DF1 Alen Bradley DF1 Alen Bradley DH465 GE Fanut SIP LG GLCA-GM Misubish PX Misubish PX Modeon MCOBUS Omron Hostlink / Mublink SIMATIC 500/505 seriell SIMATIC 57 200			
Parameters Area TP 17	0A		Station	-
Parameters Area   TP 17	ANATIC 57 300/400	Network	Station Film PLC device	-
Type	DA Interface Interface FF1 B HMI device Baud rate	Network Profile MPI 💌	Station File PLC device Address	
Type TTY R5522	OA Interface IPF1 B HMI device Baud rate	Network Profile MPT T	Station File File Address Expansion slot 0	-
Type TTY R5222 R5422	OA Interface PF1 B HMI device Baud rate 187500 Address I	Network Profile MPI I Highest station address (HSA)	Station FLC device Address 2 Expansion slot 0 Back 0	
Parameters Area Type TTY R5232 R5422 R5465	Address	Network Profile MPI Highest station address (HSA)	Station FLC device Address 2 Expansion slot 0 Rack 0	4



Brok	ect Edit Yew Insert Format	Faceplates	Options	₩ndow	Help
D	<u>Nerri</u>		h	20	G %.
	Ney, Project with Project Wizard				• B /
ti-	Open	Cb/HO	_		
	glose		1		
Π.	Save	Ctrl+5	IE	MEN	s
	Save As				-
	Change Device Type				
4	Print Project Documentation	Ctrl+P			
2	Print Selection	Orl+W			
	Complex		•		
	Iransfer		•	Transfer 3	jettings

6. Now you can start with your work. If you have finished work you can transfer this project to the panel by reading the next steps.

7. Choose "Transfer Settings" from the sub menu "Transfer".

8. In the new dialog change the "Mode" to "serial" and set the "Station address" of the operator panel (e.g. "1"). Please set the baud rate to "19200". The "Delta transfer" is not supported by the S5-LAN. Turn them so "Off".

Select devices for transfer				×
Device_1 (TP 170A)	Settings for Device, Mode Station address	_1 (TP 170A)	Transfer to Flash C RAM Delta transfer On Off Enable backtransfer Overwrite password list Overwrite recipe data records	
			Transfer Apply Cancel	9. Press

the button "Transfer" to start communication with the terminal. Your project is about to be transferred. The communication with the operator terminal is so successfully established .

### 6.3.7 Communication WinCC flexible with S5-LAN++

S5-LAN++ behaves like a CP 343-1 or as an HMI ProfiNet connection. So you use the same configuration as when you are connected to the Simatic S7 300/400 with TCP/IP.

Here's a short guide for setting WinCC Flexible:

1. Select in the S5-LAN++ as S5/S7 server port 102!

This port is usually by default setting ready at 102.

2. Select for a communication driver in the WinCC flexible SIMATIC S7 300/400 as shown in the picture. For the PLC you enter the IP address of the S5-LAN++. The Typ select to "IP". Rack- and Slotnumber is for the usage with S5-LAN++ not significant. Just enter the default data: Rack 0, Slot 2.

	7 Weiden - info@traeger.de	e _ +49 (0)961 48 23 0 0		INDUSTRY COMPO
erbindungen 🗨 Variabl	en Bild_2	BitStruct Bild_	3 Geräteeinstell	ungen 🔲 Bild_4
			VE	RBUND
Kommunikations	treiber Online	Kommentar	1	
SIMATIC S7 300/400	) Ein			
/				
Diesen Treiber auswählen				
			Die Sta	tion ist S5-LAN++
				X
sreichszeiger				
Durahing.				
Schnittstelle				× Stat
Ethernet	~			2
t auf IP stellen!			IP-Adresse	des S5-LAN++
Ber	diengerät			
Adresse	97			Adresse
172, 100, 0, 1	<u> </u>			192 , 1
Die Adresse kann nur a projektiert werden	am Gerät			Baugruppenträge
Zugangspunkt szow	THE			
Edgangspanne S70N	IL ITVE			Zyklischer Betr
-Schnittstelle einstelle	1			
fsweg LLDP				
angspunkt der Applikation:				
ONLINE (STEP 7)> T	CP/IP -> NdisWanIp	~		
ndard für STEP 7)				
utzte Schnittstellenparametrier	una:			
P/IP -> NdisWanIp		enschaften		
<pre>keine&gt;</pre>		iagnose		
ISO Ind. Ethernet -> VMware	Accel			
TCP/IP -> NdisWanIp		opieren		
ITCP/IP -> VMware Accelera	ted Alv 🥪	Löschen		
	100	# N. A. R. A. R		

3. Please note that the access point (S7ONLINE) is set correctly. The attitude you take in the Control Panel under "Set PG/PC Interface". Make sure that an adapter with TCP / IP support is selected.

4. Addressing

The conversion from S5-float (KG-format) to S7-float (IEEE 754) is automatic in both directions. It is important to use a variable type of IEEE 754. The addressing of memory bits, inputs, outputs, timers and counters is the same for S5 and S7. However, there are differences in the data blocks. Addressing at the data blocks has been adapted to the S7.

For example:



DB10 DW 10 (S5) is addressed with DB10.DBW20 (S7).

The background is that the S7 principle addresses in byte. If you want to read a single byte, for e.g. DB10.DL4 (S5), so you have to address DB10.DB88.

It is therefore necessary:

even byte address = DL, odd address = DR in DB of the S5. Here are some examples of address:

Simatic S5	Simatic S7	Format
MB 11	MB 11	Byte
MW 20	MW 20	Word
DB10 DW 9	DB10 DBW 18	Word
DB10 DW 60	DB10 DBW120	Word
DB10 DL 3	DB10 DBB 6	Byte
DB10 DR 3	DB10 DBB 7	Byte
DB10 DD 25	DB10 DD 50	DWord
DB10 DD 35	DB10 DD 70	Real

How can we address a DX (for e.g. extended DB135) Must be for e.g. a DX addressed in a CPU 135, then the following rule applies:

DB-number 1-255 = DB, DB-number > 255 = DX.

### 6.3.8 ProTool/Pro v6.0 SP2

1. Start ProTool/Pro by using the desktop link or program entry in the start menu.

2. Choose from the menu "File" the sub menu "New" or click on the right symbol.



3. The next dialog askes you which operator panel you are using. Mark the used panel (e.g. "TP 170A")



4. "Next" leads you to a new dialog. Type in the specific fields the name of the PLC device and choose the used PLC in the driver selection (e.g. "SIMATIC S5 – AS511 V6.0")

TRAEGER.DE Söllnerstr. 9 . 92637 Weiden . info@traeger.de . +49 (0)961 48 23 0 0





5. Via "Parameter..." you are calling an configuration dialog from the chosen PLC driver Select the used "CPU type" and the "interface" to which the terminal is connected (eg "IF1 A").

6. Furthermore you configure the parameters of the interface ("type", "bits", "Parity", "Stop Bits", "baud rate").

7. Confirm with "OK" until you got back to the "PLC Selection".Go on with "Next".

8. In the main window start the Transfer Settings dialog by clicking on "File" "Transfer" "Settings...". Choose "Serial" and the COM interface of the operating terminal (e.g.: "COM1"). set the baud rate to "19200". Confirm with "OK". and start with your work If you have finished working on this project you can go on with the next steps.

🎉 SI	мат	IC Pro	oTool/F	Pro CS D	EMO - To
Eile	<u>E</u> dit	⊻iew	Insert	<u>S</u> ystem	Options
<u>N</u> e	w			Ct	rl+N
Op	en			Ct	rl+0
Cļo	se				
Sat	ve			Ct	rl+S
Sa	ve <u>A</u> s				
Co	n <u>v</u> ert				I
Int	egrat	e in ST	EP 7 pro	ject	
Co	py fro	m STE	P 7 proje	ect	
✓ Pro	Tool	Integra	ation in S	TEP 7	
<u>R</u> e	place				<u> </u>
<u>C</u> ol	mpile.			Ct	rl+G

9. If you want to transfer you project to the panel you have to generate the project first. This can be done with a click on "File" - "Compile".



10. To transfer the project just click on "File" "Download" "Start Project Download" or click on the right



### symbol 🚔

Please wait while the project is transferred. The communication between the operator panel is now established.

### 6.3.9 S5 for Windows v5.02

1. Start the "S5 for Windows" software by using the link on your desktop or use the link in your start menu (standard is "Programs\S5 for Windows\S5 for Windows")

2. Choose File - >Preferences... (top left in the menu bar) to configure the communication configuration between the computer and the PLC.

3. A new dialog appears which offers the possibility to set up a lot of configuration data about the communication with your PLC.

55 / S7 for Windows® - [PC I		
File Block Options Window		
New		
Open F11		
Save F12		
Save <u>A</u> s Shift+F12		
Na <u>m</u> e Shift+F11		
Statistics		
Import		
Export		
Program File		
Symbolic Table File		
57 Configuration data		
Company hun Files		
Compare two Files		
Preferen <u>c</u> es		
ferences Interface Editor Status Listings Presentation I	onts Miscellaneous BlockDiff	ſ
erences terface   Editor   Status   Listings   Presentation   Preferences from:	Fonts   Miscellaneous   BlockDiff   Serial Port: COM <u>1</u> <u>O</u> <u>9</u> 600	
erences erface Editor Status Listings Presentation I Preferences from:	Fonts Miscellaneous BlockDiff Serial Port: COM <u>1</u> Baud Rate: <u>9600</u> COM <u>2</u> 192 <u>0</u> 0	
erences terface Editor Status Listings Presentation I Preferences from: © PC © Project Eile PLC Type: © S5 © S7	Fonts         Miscellaneous         BlockDiff           Serial Port:         Baud Rate:           COM 1         Baud Rate:           COM 2         9600           COM 2         19200           COM 3         38400	
erences Prefece Editor Status Listings Presentation P Preferences from:	Fonts         Miscellaneous         BlockDiff           Serial Port:         Baud Rate:           COM 1         Baud Rate:           COM 2         9600           COM 2         19200           COM 3         38400           COM 4         56000	
errences erface Editor Status Listings Presentation P Preferences from: © PC © Project <u>File</u> PLC Type: © S <u>5</u> © S <u>7</u> Protocol: © ASE11 (Simplin SE)	Fonts         Miscellaneous         BlockDiff           Serial Port:         Baud Rate:           COM 1         Baud Rate:           COM 2         19200           COM 3         38400           COM 4         56000	
erences erface Editor Status Listings Presentation I Preferences from: © EC © Project Eile PLC Type: © S5 © S7 Protocol: © AS511 (Simatic-S5)	Fonts         Miscellaneous         BlockDiff           Serial Port:         Baud Rate:           COM 1         9600           COM 2         19200           COM 3         38400           COM 4         56000           Excusive         57600	
erences erface Editor Status Listings Presentation Preferences from: PC Project File PLC Type: S5 O S7 Protocol: AS511 (Simatic S5) S5 - SoftPLC external	Fonts         Miscellaneous         BlockDiff           Serial Port:         Baud Rate:           COM 1         9600           COM 2         19200           COM 3         38400           COM 4         56000           Excusive         115200	
erences erface Editor Status Listings Presentation I Preferences from: PLC Type: S5 O S7 Protocol: AS511 (Simatic S5) S5 - SoftPLC external S5 / S7 - SoftPLC internal	Fonts       Miscellaneous       BlockDiff         Serial Port:	;
erences erface Editor Status Listings Presentation I Preferences from: © EC © Project Eile PLC Type: © S5 © S5 © S5 © S5 © S5 © S5-SoftPLC external © S5 / S7 - SoftPLC internal © INAT TCP/IP Automatic	Fonts       Miscellaneous       BlockDiff         Serial Port:	
rences  reface Editor Status Listings Presentation I  references from:      EC Project Eile  LC Type:      S5     S	Fonts       Miscellaneous       BlockDiff         Serial Port:       O 200 1       O 9600         COM 2       O 19200       O 19200         COM 3       O 38400       O 56000         COM 4       O 56000       O 57600         Excusive       C 115200       O 115200         MPI Converter:       I Only Master at the Bus       S7W MPI Address:       O	;
rences  erface Editor Status Listings Presentation I references from:	Fonts       Miscellaneous       BlockDiff         Serial Port:	
erface Editor Status Listings Presentation I references from: • EC • Project Eile * CType: • S5 • S5 • S5 • S5 • AS511 (Simatic S5) • S5 • SoftPLC external • S5 / S7 • SoftPLC internal • INAT ICP/IP Automatic • INAT ICP/IP Automatic • INAT H1 Connection • Simatic NET (Simatic S7)	Fonts       Miscellaneous       BlockDiff         Serial Port:	;
erface Editor Status Listings Presentation I Preferences from: © EC © Project Eile PLC Type: © S5 © S7 Protocol: © AS511 (Simatic-S5) © S5 - SoftPLC external © S5 / S7 - SoftPLC internal © INAT ICP/IP Automatic © INAT ICP/IP Automatic © INAT H1 © Connection © SimaticNET (Simatic-S7) © MPI Converter Cable (Simatic-S7)	Fonts       Miscellaneous       BlockDiff         Serial Port:       ○       G0M 1       ○       9600         ○       COM 2       ○       19200       ○       19200         ○       COM 3       ○       38400       ○       56000         ○       COM 4       ○       56000       ○       57600         ○       Excusive       ○       115200         MPI Converter:       ✓       Only Master at the Bus       S7W MPI Address:       0         MPI Address PLC:       2       2       Select PLC       2	
erences  erences  erences  ereface Editor Status Listings Presentation Preferences from:    Pc Pc Project Eile   C Project Eile  PLC Type:  S55 S5 S	Fonts       Miscellaneous       BlockDiff         Serial Port:	
erences         terface       Editor       Status       Listings       Presentation I         Preferences from:	Fonts       Miscellaneous       BlockDiff         Serial Port:       COM 1       Baud Rate:         ○       COM 2       9600         ○       COM 2       19200         ○       COM 3       38400         ○       COM 4       56000         ○       COM 4       57600         ○       Excusive       ○         MPI Converter:       ✓       Only Master at the Bus         S7W MPI Address:       0         MPI Address:       0         MPI Address:       15	
erences         terface       Editor       Status       Listings       Presentation I         Preferences from:	Fonts       Miscellaneous       BlockDiff         Serial Port:	

4. Choose the first registry card "Interface" (standard) and set up the configuration data as descriped



below:  $\Rightarrow$  Interface Settings from : "PC"

⇒ PLC type: "S5"

 $\Rightarrow$  Protocol: "AS511 (Simatic - S5")

 $\Rightarrow$  Serial Port: Select here the COM port for the AG-access

 $\Rightarrow$  Baud Rate: Choose the speed you want to use at the bus 4.

5. After the software is configured , click "Select PLC" in the area "MPI Converter". A new dialog appears where you can select the desired PLC

Select PLC	<u>? ×</u>
Available MPI-Addresses:	2
QK Abort	Help
<u>QK</u> Abort	Help

6. In this dialog you can see all PLC's which are connected

to your PC. Choose from the list box (left) the desired station (the PLC) and confirm with "OK". (In the example "2")

7. Close the preferences dialog by pressing the "OK" button.



8. Back in the main window press the "PC Block List" button for testing the new established communication configuration.

9. Please wait a moment for the software to read the desired blocks from the PLC. The blocks will be displayed in the listbox below the menu bar (see picture to the right).

#### TRAEGER.De Söllnerstr. 9 . 92637 Weiden . info@traeger.de . +49 (0)961 48 23 0 0



Baust	tein	Adress
OB	1	-
SFC	0	-
SFC	1	-
SFC	2	-
SFC	3	-
SFC	4	-
SFC	20	-
SFC	21	-
SFC	22	-
SFC	28	-
SFC	29	-
SFC	30	-
SFC	31	-
SFC	32	-
SFC	33	-
SFC	34	-
SFC	36	-
SFC	37	-
SFC	38	-
SFC	39	-
SFC	40	-
SFC	41	-
SFC	42	-
SFC	43	-
SFC	44	-
SFC	46	-
SFC	47	-
SFC	49	-
SFC	50	-
SFC	51	-
4		

The communication between the S5 for Windows and the PLC is now established.

### 6.3.10 S5-gateway communication (coupling)

1. Start the S5-LAN Manager, search for your module, select it and click with the mouse on "S5-gateway connection". This opens a dialog to set the connection.

erbind	lungs-Nr:	1						
lame:		Example						
Configu	irations-DB:	1 ab D	w O					
/erbind	lungs-Typ:	ISO-on-TCP-	Verbindu	ing	<b>a</b>	ktiver Verbindu	ungsaufbau	
olizyki	us:	0	ms					
Adress	en							
	lok	al			Par	ner		
P-Adre	esse 193	2.168.2.103			1	92 . 168 .	2 . 101	
Port	0				0			
TSAP	(ASC) U	nique			Un	ique		
	Länge 6				6			
ISAP-	I SECOND	Тир	aktiv	P-Zvklus	Konfia-DB	IP-Partner	Port Lokal	Po
TSAP-	Name	ISO on		0	DB1.DBW0	192.168	0	0
rsap-	Exam			0	DB0.DBW0	0.0.0.0	0	0
rsap- Nr	Exam	ISO on						

2. In the bottom of the dialog, click the link in the list you choose to configure the connection.

3. At the top you can give the connection a logical name.

4. Among them, configure the position of the "configuration data block". For this, type in the position of the data blockin the left field (for example, "1" for DB1) and from which data word ("from DW") ranges the configuration.

5. As "Connection Type" is set "ISO-on-TCP connection". In this setting is used the TCP port 102.

6. The polling cycle (ms) indicates the elapsed time until the S5 the Gateway configuration area cyclically reads and examines, what is to do. when a 0 is specified then will be read constantly from the PLC.

7. In the field addresses you can only specify the IP address of the partner. The IP address of the Gateway you continue to configure S5 over the S5-LAN Manager.

If 0.0.0.0 is specified as partner IP address, the IP address is not checked when connecting. Thus any device can set up a connection that knows the TSAP of the S5 gateways.

8. On both devices you can stipulate the TSAP (Transport Service Access Point). This consists of 16 characters, and represents the identification of the connection. This is needed when several connections with an IP address are available.

Starting with firmware version 0.45 of the S5 Gateway a connection can be established with any TSAP, if the partner is specified nothing at TSAP (partner TSAP length = 0). For this the member just needs the IP address and the TSAP of the S5 gateways.

9.Communication with the "ISO-on-TCP connection" of the CP343-1 is compatible. Thus need to be coupled with S7 CP343-1 only the relevant connections are configured. Ask the TPDU size (Transport Protocol Data Unit) to "512". This sets the maximum data size that can be received or sent.

The communication to the S5 is handled via the PG interface. There is used a baud rate of 9600 bits /





second. Of course this protocol needs longer maturities. Therefore, make sure that the partner sends data to the S5 Gateway module not too quickly. Otherwise it may lead to a task traffic jam. In an exchange of about 256 bytes a transmitter switch of at least 600 ms is recommended, even better would be 1000 ms. Communication will be configured via the S5 gateway.

#### 6.3.10.1 Technical information for the configuration area

Format of the configuration area:

	DL								DR							DW	
	7	6	5	4	3	2	1	0	7	6	5	4	3	2	1	0	
receive	res	ser	ve	d					RT	ΥP	('C	)',	'Χ',	′Μ',	'Ε',	'A')	0
	RD	RDBN (at 'D' or'X' block number)										1					
	RB	EG	i (a	t '[	D' (	or '	X'	Sta	rtD	W	ot	ner	wi	se St	artE	Byte)	2
	RL	ΕN	(S	ize	of	th	e re	ece	eive	e m	ail	box	k ir	ı byt	es)		3
	res	ser	ve	d													4
send	res	ser	ve	b					ST	YΡ	('C	)', '	Χ',	'Μ',	'Ε',	'A')	5
	SD	BN	I (a	nt 'I	D' (	or '	X'	blo	ck	nu	mk	er	)				6
	SB	EG	i (a	t '[	D' (	or '	X' :	Sta	rtD	W	otl	ner	wis	se St	artE	yte)	7
	SL	ΕN	(S	ize	of	the	e re	ece	ive	m	aill	00	( in	byt	es)		8
	res	ser	ve	d													9
send	Τх	LEI	N (9	ser	nd -	le	ngi	:h i	n b	yte	es)						10
	Тx	ST/	AT	(tr	ans	smi	t s	tat	e)								11
	res	ser	ve	d					res	ser	ve	k		DO NE	ER R	AC T	12
receive	Rx	LEI	Ν(	rec	eiv	/e l	en	gth	in	by	tes	5)					13
	Rx	ST	AT	(re	ece	ive	st	ate	)								14
	reserved reserved R R T						AC T	15									
reserved for	reserved								16								
Extension	res	ser	ve	b													17
	res	ser	ve	b													18
	res	ser	ve	b													19

The individual fields in the detail:

		function block	access	
Designation	Meaning	parameter name	R = read	W=write
RTYP	Data type of the receive mailbox: 'D' = DB 'X' = DX 'M' = flag 'E' = input 'A' = output	RTYP	R	W
RDBN	If RTYP DB or DX block number otherwise no use.	RDBN	R	W
RBEG	The beginning of the receive mailbox. If DB and DX data word is starting, otherwise start byte.	RBEG	R	W
RLEN	Length of the receive mailbox in bytes (even if DB).	RLEN	R	W



		function block	access	
Designation	Meaning	parameter name	R = read	W=write
STYP	Data type of the send mailbox: 'D' = DB 'X' = DX 'M' = flag 'E' = input 'A' = output	STYP	R	W
SDBN	If STYP DB or DX block number otherwise no use.	SDBN	R	W
SBEG	Beginning of the send mailbox. If DB and DX is starting - data word, or start - data byte.	SBEG	R	W
SLEN	Length of the send mailbox in bytes (even if DB).	SLEN	R	W
TxLEN	Number of bytes that should be sent.	LEN	R	W
TxSTAT	Send Status evaluate if DONE or ERR is set to 1. If DONE is 1, so the order was executed without error. STAT is 0	STAT	W	R
TxACT	Start a send job in S5 - LAN.	ACT	R/W	R/W
TxERR	Is 1 if an error has occurred. The error can be seen in detail the STAT field.	ERR	W	R/W
TxDONE	Is 1 if the job was executed successfully end.	DONW	W	R/W
RxLEN	Number of bytes that have been received	LEN	W	R
RxSTAT	Reception status once when DONE or ERR is set to 1. If DONE is 1 the order was executed without error. STAT is $0$	STAT	W	R
RxACT	Releases the receive mailbox if 1	ACT	R/W	R/W
RxERR	Is 1, if an error has occurred. The error can be seen in detail the STAT field.	ERR	W	R/W
NDR	Is 1 if data has been received (data received). RxLEN then evaluate.	NDR	W	R/W

It is provided for an easy communication of the FB55 (S5L\_SEND) and FB56 (S5L\_RECV). In these blocks is handled the communication between the gateway and S5 PLC. The FB's have been developed based on the S5 communication FC's (FC5, FC6, AG-SEND or AG-RECV).

NOTE: These devices use 200 MW and 202 MW as used flags.

It should be noted that individual statuses ERR, DONE, NDR only lie flat one cycle for each case. It will then executed the required steps (STAT evaluate or receive mailbox empty, etc.). Please see the description of the input / output parameters in the table above.

The following states can adopt the STAT field:

STAT	on ca	all of S	5L_SEND
DONE	ERR	STAT	Meaning
1	0	0000H	Job completed without errors
0	1	8304H	Connection is not established
0	1	8185H	Send mailbox is too small SLEN
0	1	8184H	Illegal data type specified for the send mailbox
0	1	FFFFH	General Error
STAT	on ca	all of S	5L_RECV
DONE	ERR	STAT	Meaning
1	0	0000H	Data has been received (LEN check and get the data)
0	1	8304H	Connection is not established
0	1	8185H	Receive mailbox is too small RLEN



STAT	on ca	all of S	5L_SEND
DONE	ERR	STAT	Meaning
0	1	8184H	Illegal data type specified for the receive mailbox
0	1	FFFFH	General error

In the following example the DB20 is used as the configuration DB. E 4.0 controls the sending and E 4.1 controls the receiving. If E 4.0 is '1 ', then will be sent 10 bytes of DB100 from DW 0. E 4.1 gives free the receive shelf DB100 DW from 100 with 10 bytes.

	:	SPA	FB	56
Name	:	S5L_SEND		
JDBN	:		KF	+00020
JDBW	:		KF	+00000
STYP	:		KC	D
SDBN	:		KF	+00100
SBEG	:		KF	+00000
SLEN	:		KF	+00010
ACT	:		E	4.0
LEN	:		KF	+00010
DONE	:		М	
ERR	:		М	11.1
STAT	:		MW	20
	:			
	:	SPA	FB	56
Name	:	S5L_RECV		
JDBN	:		KF	+00020
JDBW	:		KF	+00000
RTYP	:		KC	D
RDBN	:		KF	+00100
RBEG	:		KF	+00100
RLEN	:		KF	+00010
ACT	:		E	4.1
LEN	:		MW	24
NDR	:		М	13.0
ERR	:		М	13.1
STAT	:		MW	22

### 6.3.11 TIA-Portal

Samples from Siemens:

#### S7- 1500

https://support.industry.siemens.com/cs/document/82212115/wie-projektieren-und-programmieren-sie-f% C3%BCr-den-datenaustausch-zwischen-zwei-s7-1500-cpus-eine-s7-verbindung-und-die-kommunikationsanweisungen-put-und-get-?dti=0&lc=de-WW

#### S7- 1200

https://support.industry.siemens.com/cs/document/65975617/wie-werden-die-anweisungen-get-und-put-im -anwenderprogramm-der-simatic-s7-1200-cpu-programmiert-um-mehr-als-160-byte-daten-zu-%C3%BCbertragen-?dti=0&lc=de-WW



#### S7-400

https://support.industry.siemens.com/cs/document/1819293/programmbeispiel%3A-s7-kommunikation-mit -den-bausteinen-sfb14-(-get-)-und-sfb15-(-put-)-bei-der-s7-400?dti=0&lc=de-WW

#### S7-300

https://support.industry.siemens.com/cs/document/18610307/wie-werden-die-kommunikationsbausteine-fb 14-get-und-fb15-put-f%C3%BCr-den-datenaustausch-im-s7-programm-einer-s7-300-cpu-programmiert-?dti=0&lc=de-WW

## 7 Configuration

### 7.1 S5-LAN Manager

Start the S5-LAN Manager from either the start menu or in the PLC-VCOM menu under "Configuration"

	Тур	IP (aktuell)	IP (im Gerät)	MAC-Adresse	Version	Status
Schrank EG	S5-LAN	192.168.1.109	192.168.1.109	00-20-4A-A9-FB-75	0.72	running
lest BE	55-LAN++	192 168 1.83	192.168.1.83	00-20-4A-8D-7D-4E	1.18	running
. 1						
Tirmwareinfo						
Dateiname: [ [ Status: [						
			Suche im lokalen	n Netz Fir	mwaredate	i laden
		_	Sucha bastimmta /		irmuoro oo	ndan
			Suche Destimitie A	Adresse	inniware se	nuen
		S	5-Gateway Verbind	dungen	Einstellunge	en

Search in local network By clicking on the "Search in local Network" you send a broadcast to all modules which are located on your network. Every Reacting module is entered into the list.
 Search specific address: If you already know the IP address of the S5-LAN module you can enter these in the following dialog with a click on "particular Search address" and search for with a click on "search".

TRAEGER.D∈ Söllnerstr. 9 . 92637 Weiden . info@traeger.de . +49 (0)961 48 23 0 0





**S5 gateway connections:** This dialog is displayed only for S5-gateway modules. With this it is possible to establish connections to other controllers. More details to this dialog refer to the Chapter " S5-gateway communication (coupling) ".

Verbind	dungs-Nr:	1						
Name:								
Konfigu	urations-DB:	0 ab D	w 0					
Verbind	dungs-Typ:	ISO-on-TCP-Verbindung				ungsaufbau		
Pollzyk	lus:	0	ns					
Adress	en	<u> </u>						
		lokal			Part	ner		
IP-Adresse		192,168,1,83	192.168.1.83 0 . 0 . 0					
Port		0			0			
TSAP	(Hex)	-						-
TSAP	Länge ()				0			
Nr	Name	Тур	aktiv	P-Zyklus	Konfig-DB	IP-Partner	Port Lokal	Po
1	101	ISO on		0	DB0.DBW0	0.0.0.0	0	0
2		ISO on		0	DB0.DBW0	0.0.0.0	0	0
-						1		>

Language: Sets the language of the program between German and English.

**Firmware file load:** To send a firmware file, it must first be loaded. This is done by clicking the button "Load Firmware File." It appears a dialog for selecting the appropriate \*.bin (binary) firmware file. Select the appropriate firmware file and click OK. Firmware-specific information now are displayed in the section firmware info.

**Send firmware:** Once you have loaded the firmware file, this button is activated. Select the module and then select this button to send the firmware. **NOTE:** It is highly recommended only to renew the firmware of the module if you have problems with the old version of module operation.

While the firmware is transmitted to the module and the module operation version is renewed, the module may not be removed from the network or from the power, otherwise is the danger that the module does not work properly.

**Settings:** Click on Settings to change the properties in the following dialog of the S5 module. Click "OK" to save the new settings and close the dialog.

Gerätename:	Test	
65-PG-Port:	10010	
67/S5-Server-Port	102	
	DB Adresse zyklisch lesen	
IP-Adresse	DB Adresse zyklisch lesen	
IP-Adresse	DB Adresse zyklisch lesen	
IP-Adresse DHCP /Auto IP-Adresse: Subnet-Maske:	DB Adresse zyklisch lesen	ОК

**Name of the device** The device name can be any text. So you can clearly identify each S5/S7-Modul. **S5 PG port:** TCP / IP port number. About this port your S5 module and PG communicate together. Must be not normally changed. (Default: 10010) **S5 server port:** TCP / IP port number. Over this port is handled the S5-LAN + + - LINK protocol. (Default: 2002) **DHCP/AutoIP:** If this box is active, at the start the module searches a DHCP server to get an IP address. If no server could be found after 3 attempts (may take a few seconds), the module will use an IP address from the "Auto IP" address range. **Auto subnet:** If set, the module calculates the subnet mask automatically. e.g. at 192.168.0.80 this is the 255.255.255.0. In this case nothing needs to be entered in the subnet mask field. **IP adress:** If DHCP / AutoIP off, here can be entered the IP address of the S5 module. **Subnet mask:** Here you define the subnet mask. At 0.0.0.0 as input auto Subnet is enabled. **Default Gateway:** Operate the LAN module on a router, you type in the IP address of the router.

Make sure that the IP address you give to your module / cable (the same if S5-LAN or LAN-MPI), match to your network and is only awarded once. Likewise the PC which communicates with the cable, should have an appropriate IP address. If you are not sure what IP address you can assign, you should contact your network administrator.

#### 7.1.1 Ports

Port	Туре	Description
65467	UDP	Search from S5-LAN + +, by using S5-LAN Manager / PLCVCOM
10010	ТСР	PG port (PLCVCOM)
2002	ТСР	S5 server port (VIPA)
102	ТСР	S5 server port (RFC1006)

## 8 PLC-VCOM

## 8.1 Description

It creates a new, virtual com-port in your system, with which the programming software of your PC (such a. PG 2000, Step© 5/7, S5/S7 for Windows, WinCC, Microwin) can communicate with the device

The PLC-VCom application is needed for use with the following devices:

2. After choosing language the welcome dialog appears in the chosen language. Click "Next" to define the installation path (see right picture). This can be done with a click "Browse..." If you are ready press "Next" to go to the solution of the solution



3. In the next dialog you can choose the program folder for your start menu.

### 8.2<sup>wit</sup>mstallation

### b Download the PLCVCom from the product-page of your MPI-product and start the installation. 8.2.1 FINAL CONTIGURATION OF THE PLC-VCOM

com PLC VCom V2.00	×
Please select the name of the virtual com port	
СОМЗ 💌	
OK	

8. Choosing the COM – Port Already occupied COM port can be viewed in Windows Device Manager if you are not sure which COM ports are still available.

If you are not sure which port is unused, press "OK". Later you can start this dialog again by clicking in the application folder of your start menu on "SelectCOM".

SelectCo	m X
1	In order to work with the new setting, you must restart the PLCVCOM-application
	OK

9. The installation ends with a click on "OK".

### 8.3 Overview

Beside your watch, in your Windows – Taskbar, appears a new Symbol. This one is for the PLC – VCom software.

It shows the actual connection status with your cable/module MPI-II, MPI-USB, MPI-LAN, S7-USB, S7-LAN or S5-LAN.

### 8.3.1 Status description:

110	PLC – VCom is connected with your cable/module and operational.
×	PLC – VCom is not connected.
×	The red symbol indicates that sending/receiving data has been failed. Send status: (left field): Data is send to the cable/module if this one is green.



Receive status: (right field): Data is received from the

cable/module if this one is green.

### 8.3.2 Main Window

III PLC-VCom	
Konfiguration	Info
Status S7/MPI-LAN verbunden IP	192.168.1.151 Konfigurieren
Name	Test KM
Rechnerverbindung IP	192.168.001.066 PLCVCOM
virtueller Port COM3 geöffnet von Programm Beenden Sprache	PG-2000 Hilfe Minimieren

**1. Configuration:** Select and open the configuration program for your products.

 $\Rightarrow$  PLC-VCOM: Management, connection and communication with the cables

 $\Rightarrow$  S5-LAN: configuration of your S5-LAN modules

 $\Rightarrow$  MPI/S7-LAN: Configuration of your MPI-LAN or S7LAN

**2. Info:** information about the PLC-VCOM and your computer.

3. Status: Display the connection parameters of the cable connected.

- $\Rightarrow$  Top left: shows the name of the currently connected product
- $\Rightarrow$  semi-left: shows the connection status
- $\Rightarrow$  half right: shows the IP address of the connecting cable
- $\Rightarrow$  Top right: Click here to search or select a device
- $\Rightarrow$  right middle: name of the connected cable

 $\Rightarrow$  bottom right: displays information about current computer connections

4. Virtual Port: Display of selected virtual COM ports and

the program that the last has accessed on this COM port.

#### 5. Program: Buttons to adjust the PLC-VCOM

 $\Rightarrow$  Exit. This button closes the program and the COM – Port

 $\Rightarrow$  Lenguage: Switch the Language to english/german.

 $\Rightarrow$  Help: opens the Help menu of the PLC-VCOM, when they should have problems or questions

 $\Rightarrow$  "Minimize" the dialog. This button does not close the program. It just minimizes the program. You will find the PLC – VCom symbol in the Windows – taskbar beside the watch.

S5-LAN++



### 8.3.3 Configuration window

#### LAN - IP - VCOM - Zuordnung

rianic	LAN - Typ	IP-Adresse	MAL-Adresse	Version	Serien-Nr	Port	Neta
Test KM	S7/MPI-LAN	192.168.1.151	00-0B-F4-72-ED-E9	2.09	7532009		0
20.0			1111				1.2
()							
Adresse:	192 . 168 . 1		2:ED:E9	]		Suc	hen
ber Netz-	0:Realtek RTL8168C	(P)/8111C(P) PCI-E Gigat	oit Ethernet NIC - Paketi 🔽	Ĩ.		_	
erkkarte		manue	lle Eingabe	serielle Paus	enzeiten	Hi	ife
AN-Type:	S7/MPI-LAN	× -					
		📃 kein N	etzwerk				K
		📃 İnstalla	ition im Gerätemanager			Abbre	-la -u

#### 1. List of available cable / modules:

 $\Rightarrow$  Linewise display of the products found with your properties

#### 2. IP-Adress:

 $\Rightarrow$  IP address and MAC address of the selected cable / module

#### 3. Via network card:

 $\Rightarrow$  Selection of the used network interface card

#### 4. LAN-Type:

 $\Rightarrow$  Selection of the be connected cable / Module Types

#### 5. Several check boxes:

- $\Rightarrow$  Manual entry: allows you to enter the parameters manually
- $\Rightarrow$  no network: for products which are not in any network
- $\Rightarrow$  Installing in the device Manager: Installs the PLC-VCOM COM port in Device Manager
- (required only for S7 for Windows and S7 Doctor software)
- $\Rightarrow$  RFC1006: activation of RFC1006 communication method
- $\Rightarrow$  no network card selection: Passes the routing of packets to the operating system
- $\Rightarrow$  serial interval times: slow down the serial transmission eg panel transfers

#### 6. Search

 $\Rightarrow$  With a click on Search you are sending an broadcast to every cable/module that is connected with your network or your system. Every responding cable/module will be inserted to the list.

#### 7. Help:

 $\Rightarrow$  opens the Help menu of the configuration, if they have problems or questions

#### 8. OK:

 $\Rightarrow$  Ends the PLC-VCOM configuration and accepts the entered / selected settings

#### 9. Cancel:

 $\Rightarrow$  Ends the PLC-VCOM configuration and discards the entered / selected settings



### 8.4 Configuration

1. Start the PLC – VCom application, if this is not already running.

2. Open the PLC-VCOM by clicking on the icon  $\blacksquare$  PLC-VCOM in the system tray.

3. After the PLC-VCOM is open, click in the status area on the "Configure" and the wizard to configure is launched.

### 8.4.1 S5-LAN / S5-LAN++

Test KM	S5-LAN++	192,168,1.54	00-20-4A-BC-F6-85	1.16	0000000	10010	0
c							1.5
Adresse:	192 . 168 . 1	. 54 00:20:44	BC:F6:85	]		Such	hen
ber Netz-	D:Realtek RTL8168C(	P)/8111C(P) PCI-E Giga	abit Ethernet NIC - Paketj 💊				
AN-Type:	S5-LAN++	manu	elle Eingabe 📃	serielle Paus	senzeiten		-
5-PG-Port:	10010	kein f	Netzwerk ation im Gerätemanager				(

#### 8.4.1.1 Automatically

1. Click on "Search" to send a broadcast to all cables and modules which are located on your network or directly connected to the computer. Each on this broadcast responsive cable / module is entered in the list of participants.

2. Select the desired cable / module so that them are highlighted in blue. Here are all parameters automatically included in the configuration wizard.

#### 8.4.1.2 Manual

The manual entry relates to the network users who are behind a router, located in other networks because of the broadcast for the automatic detection is not propagated by routers and therefore network users can not be found.

1. If you know the IP address of your cable, you can enter it manually. To activate the entry field for this purpose, click on the box "manual entry".

2. Enter at "IP address", the address of your cable / module that you want to connect to and select your type of cable in the "LAN Type".

TRAEGER.DE Söllnerstr. 9 . 92637 Weiden . info@traeger.de . +49 (0)961 48 23 0 0



#### 8.4.1.3 Final settings

3.In the S5-LAN is unlocked the additional field S5 PG port. At the selection this will be automatically filled with the value that is stored in the S5-LAN or enter this port at a manual input by hand. This port can be changed using the S5-LAN Manager in the S5-LAN.

The S5-PG port is the programming port of the S5-LAN and is by default 10010.

The S5-PG port, which is registered in the PLC-VCOM, must always match with the S5-PG-Port registered in the S5-LAN!

4. Select the options that you may need, such as no network card selection or serial break times.

Information about the options can be found in "Overview" section of the PLC VCOMs, that can be selected and deselected with the help of checkboxes.

5.Confirm your entry / selection with "OK".

PLC-VCom				
Konfiguration				Info
Status S5-LAN++	verbunden	P   	192.168.1.54 Fest KM	Konfigurieren

6. In the main window of the PLC VCOMs appears after successfully connecting the cable type, with witch the computer connects, the connection status "connected", the IP address and the name of the connected participant.

7. Finally click "Minimize" to decrease the PLC-VCOM in the notification area so that it can continue to manage the virtual COM port.

### 8.4.2 S5-Gateway / S5-Gateway+

LAN - IP - VC	.OM - Zuordnung						10
Name	LAN - Typ	IP-Adresse	MAC-Adresse	Version	Serien-Nr	Port	Neta
Test KM	\$5-LAN++	192.168.1.54	00-20-4A-BC-F6-85	1.16	0000000	10010	0
<							>
IP Adresse:	192 . 168 . 1	54 FF:FF:FF:F	F:FF:FF	]		Such	nen
über Netz- werkkarte	0:Realtek RTL8168C(F	P)/8111C(P) PCI-E Gigal	oit Ethernet NIC - Paketj 💊			Hilf	ie )
LAN-Type:	S5-Gateway+	manue	lle Eingabe	serielle Paus	senzeiten		
S5-PG-Port:	10010	kein N	etzwerk ation im Gerätemanager Keine Netzwerk	kartenauswa	ahl	Abbre	chen



### 8.4.2.1 Automatically

1. With a click on "Search" you send a broadcast to all cables and modules that are located on your network or directly connected to the computer. Each to this broadcast responsive cable / module is entered in the list of participants.

2. Select the desired cable / module so that them are highlighted in blue. Here are all parameters automatically included in the configuration wizard.

#### 8.4.2.2 Manual

The manual entry relates to the network users who are behind a router, located in other networks because of the broadcast for the automatic detection is not propagated by routers and therefore network users can not be found.

1. If you know the IP address of your cable, you can enter it manually. To activate the entry field for this purpose, click on the box "manual entry".

2. Enter at "IP address", the address of your cable / module that you want to connect to and select your type of cable in the "LAN Type".

#### 8.4.2.3 Final settings

3. In the S5-LAN is unlocked the additional field S5 PG port. At the selection this will be automatically filled with the value that is stored in the S5-LAN or enter this port at a manual input by hand. This port can be changed using the S5-LAN Manager in the S5-LAN.

The S5-PG port is the programming port of the S5-LAN and is by default 10010.

The S5-PG port, which is registered in the PLC-VCOM, must always match with the S5-PG-Port registered in the S5-LAN!

4. Select the options that you may need, such as no network card selection or serial break times.

Information about the options can be found in "Overview" section of the PLC VCOMs, that can be selected and deselected with the help of checkboxes.

5. Confirm your entry / selection with "OK".

III PLC-VCom				
Konfiguration				Info
Status S5-LAN++	verbunden	_ Ib [ 	192.168.1.54 Test KM	Konfigurieren

6. In the main window of the PLC VCOMs appears after successfully connecting the cable type, with witch the computer connects, the connection status "connected", the IP address and the name of the connected participant.

7. Finally click "Minimize" to decrease the PLC-VCOM in the notification area so that it can continue to manage the virtual COM port.

## 9 Technical data

Supply voltage:	24V/DC +/- 20%
Power consumption:	2 watt
Display:	status-LED Handling/Configuration: reset-switch-key (factory setting) S5-LAN Manager



Interfaces:to the PLC: TTY/20mA current loop (S5-LAN passiv, PLC to the PD/PC: 10/100BaseTX RJ45-ethernet jack		
<b>Operating temperature:</b>	5 - 55°C	
Case:	ABS-plastic case	
Dimensions:	42 x 15 x 65 mm	

### 9.1 pin assignment power supply



Pin number	Short form	Designation	Direction
1	P24V	24V DC voltage	input
3	M24V	ground	input

## 9.2 Pinning Ethernet

Pin no.	Short name	Notation	Direction
1	TX +	receive line +	Out
2	TX –	receive line -	Out
3	RX +	send line +	In
6	RX –	send line -	In

## 9.3 Pin assignment TTY / 20mA current loop

Pin number	Short form	Designation	Direction
1	NC	not used	
2	TTY OUT +	transmit data + (transistor collector)	Out
3	NC	not used	
4	+24V	power supply +24V	In
5	NC	not used	
6	I-Tx	20mA power source transmitter	Out
7	tty in +	receive data+ (LED anode)	In
8	NC	not used	
9	I-Rx	20mA power source receiver	Out
10	Mext	ground +24V	In
11	NC	not used	
12	NC	not used	
13	NC	not used	
14	NC	not used	
15	NC	not used	



# 9.4 Pin assignment RS232 (for special-S5-LAN + + variant-RS)

Pin number	Short form	Designation	Direction
1	NC	not used	
2	TxD	transmit data	Out
3	NC	not used	
4	NC	not used	
5	NC	not used	
6	NC	not used	
7	RxD	receive data	In
8	NC	not used	
9	NC	not used	
10	GND	ground	-
11	NC	not used	
12	NC	not used	
13	NC	not used	
14	NC	not used	
15	NC	not used	

## 10 Examples of applications

## 10.1 S5 to S5 – Gateway communication

### 10.1.1 Configuration S5 gateway

Needed: S5-LAN Manager Supported since firmware - version 0.44 of the S5 - Gateway

1. Start the S5-LAN Manager and search for your module. Select it and click with the mouse on the "S5 - Gateway - Connection". This opens a dialog to set the connection.

	TRAEGER.DE Söllnerstr. 9 92637 Weiden info@traeger.de +49 (0)961 48 23 0 0								
S5-Gateway Verbin	ndungen		l l	3					
Verbindungs-Nr:	1								
Name:	Example								
Konfigurations-DB:	20 ab DW 0								
Verbindungs-Typ:	ISO-on-TCP-Verbindung	💽 🗌 aktiver Verbindu	ungsaufbau						
Pollzyklus:	1000 ms								
Adressen									
	lokal	Partner							
IP-Adresse	192.168.1.54	192 . 168 .	1.56						
Port	0	0							
TSAP (Hex)	TSAP	TSAP							
TSAP-Länge 4		4							
Nr Name	Typ aktiv P-Zyklus	Konfig-DB IP-Partner	Port Lokal Po						
1 Exam	ISO on 1000	DB20.DBW0 192.168	0 0						
2	15U on U	DR0'DRM0 0'0'0'0	UU						
<			>						
		ОК	Abbrechen						

2. In the lower area of the dialog you find the connection list, in which you choose the connection to configure.

3. In "name" you can now give the connection a logical name.

4. Under "Configuration - DB" type in the position of the data block in the left field, (eg "1" for DB1) and in right field from which data word (eg "1" for DW1) ranges the configuration.

5. As "link - type" set "ISO - on - TCP - Connection". In this setting is used the TCP port 102.

6. The polling cycle (in ms) specifies how much time elapses until the S5 - Gateway cyclically reads the configuration area and checks if something has to be done. If here is specified 0, is readed constantly from the PLC.

7. In the area of addresses you can only define the IP - address of the partner. Set the IP - address of the S5 - Gateway module to further configure the S5 - LAN Manager.

8. With both devices, you can use the "TSAP" (transportation - Service - Access - Point). This consists of 16 characters, and sets the ID of the connection represents. This is needed when several compounds with an IP - address exist. (Firmware version 0.45 of the S5 - Gateway can be built with any TSAP of a connection)

9. In the second module must be set in addition to the steps described in "Connection - Type" on the chopping the "Active connection" .

The communication via S5 - Gateway is now configured.



### 10.1.2 transfer blocks in PLC

1. Start your programming software and open now S5D - file "S5toS5 - Gateway".

2. So connect with your S5 - Gateway modules and transfer all the blocks (OB1, FB55 and FB56) into the module belonging to the PLC. The same blocks you now even transfer into the second PLC. The blocks DB20 and DB100 are generated from alone.

### 10.1.3 Transmission cycle (S5)

In the following example the DB20 is used as configuration - DB. M10.0 controls the sending and M12.0 controls the receiving. If M10.0 is "1", then 20 bytes of the DB100 are sent from DW0. M12.0 gives free 20 bytes the receive mailbox DB100 from DW100.

	:	SPA	FB	55
Name	:	S5L_SEND		
JDBN	:		KF	+00020
JDBW	:		KF	+00000
STYP	:		KC	D
SDBN	:		KF	+00100
SBEG	:		KF	+00000
SLEN	:		KF	+00020
ACT	:		М	10.0
LEN	:		KF	+00020
DONE	:		М	11.0
ERR	:		М	11.1
STAT	:		MW	20
	:			
	:	SPA	FB	56
Name	:	S5L_RECV		
JDBN	:		KF	+00020
JDBW	:		KF	+00000
RTYP	:		KC	D
RDBN	:		KF	+00100
RBEG	:		KF	+00100
RLEN	:		KF	+00020
ACT	:		М	12.0
LEN	:		MW	24
NDR	:		М	
ERR	:		М	13.1
STAT	:		MW	22

Set the inputs E8.0 and E9.0 to "1" for sending and receiving.

### 10.1.4 Test of the structure (S5)

1. Open the each DB100 in your PLCs and enter any values in the first 20 bytes. e.g.:(1; 2; 3; 4; 5; 6; 7; 8; 9) TRAEGER.DE Söllnerstr. 9 . 92637 Weiden . info@traeger.de . +49 (0)961 48 23 0 0

🔼 DB	100 -	C:\DOK	UMENTE	UND EINSTELLUNGEN\\S5ANS5-GATEWAY\S5ANS5 🔳 🔲	×
				Bib =	>
	6:	KH =	0001;		
	1:	KH =	0002;		
	2:	KH =	0003;		
	3:	KH =	0004;		
	4:	KH =	0005;		
	5:	KH =	0006;		
	6:	KH =	0007;		
	7:	KH =	0008;		
	8:	KH =	0009;		
	9:	KH =	0000;		
1	0:	KH =	0000;		
1	1:	KH =	0000;		
1	2:	KH =	0000;		
1	3:	KH =	0000;		
1	4:	KH =	0000;		
1	5:	KH =	0000;		
1	6:	KH =	0000;		
1	7:	KH =	0000;		~
<				>	

2. Save the blocks and set the inputs E8.0 and E9.0 to "1" in your PLC with the active S5 - Gateway module and restart the cycle.

🔳 STE	U	ERN VARIA	BLE		
Mark	1	Adresse	Art	Wert	Kommentar
	E	8.0	KM	1	
•	E	9.0	KM	1	
<				щ	>

3. Now open the DB100 and check if the values from the 20 bytes that you have configured in the other PLC in the DB100 matches with those from DW100.

🔼 DB 100	) - C:\DOKUMENTE UN	D EINSTELLUNGEN\\S5ANS5-GATEWAY\S5ANS5 🔳 🗖 🔀
97:	KH = 0000;	A
98:	KH = 0000;	
99:	KH = 0000;	
100:	KH = 0001;	
101:	KH = 0002;	
102:	KH = 0003;	
103:	KH = 0004;	
104:	KH = 0005;	
105:	KH = 0006;	
106:	KH = 0007;	
107:	KH = 0008;	n de la companya de l
108:	KH = 0009;	
109:	KH = 0000;	
110:	KH = 0000;	
111:	KH = 0000;	
112:	KH = 0000;	
113:	KH = 0000;	
114:	KH = 0000;	
115:	KH = 0000;	×
<		

If they match, the communication was successful.

### 10.1.5 Format of the configuration area

DL			DR						DW							
7	6	5	4	3	2	1	0	7	6	5	4	3	2	1	0	

TRAEGER DE Söllnerstr. 9 9263

received

R.DE Söllnerstr. 9 - 92637 Weiden -	info@traeger.de _ +49 (0)961 48 23 0 0	
reserved	<b>RTYP</b> ('D', 'X', 'M', 'E', 'A')	0
RDBN (at 'D' or 'X' block number)		
RBEG (at 'D' or 'X' StartDW otherwise StartByte		
RLEN (Size of the rec	eive mailbox in bytes)	3
reserved		4
reserved <b>STYP</b> ('D', 'X', 'M', 'E', 'A'		
SDBN (at 'D' or 'X' block number)		
SBEG (at 'D' or 'X' StartDW otherwise StartByte		
		i

	reserved					4		
send	reserved <b>STYP</b> ('D', 'X', 'M', 'E', 'A')							
	SDBN (at 'D' or 'X' bl	ock number)				6		
	SBEG (at 'D' or 'X' St	artDW otherw	ise S	tartB	yte)	7		
	SLEN (Size of the tran	nsmit mailbox	in by	ytes)		8		
	reserved					9		
transmit	Tx <b>LEN</b> (transmit - len	gth in bytes)				10		
	Tx <b>STAT</b> (send status)	)				11		
	reserved	reserved	DO NE	ER R	AC T	12		
received	RxLEN (receiving - lei	ngth in bytes)	-			13		
	Rx <b>STAT</b> (receive stat	e)				14		
	reserved	reserved	ND R	ER R	AC T	15		
reserved for extension	<sup>pr</sup> reserved							
	reserved					17		
	reserved					18		
	reserved					19		
	1 1 2 11 1 1 1 1							

The single fields in the detail:

Designation	Meaning	FB - parameter	Access R = read W = write	
5		liane	S5 - GW	PLC
RTYP	Data type of the receive mailbox: 'D' = DB 'X' = DX 'M' = flag 'E' = input 'A' = output	RTYP	R	w
RDBN	If RTYP DB or DX block number otherwise no use.	RDBN	R	W
RBEG	The beginning of the receive mailbox. If DB and DX is starting - data word, or start - data byte.	RBEG	R	W
RLEN	Length of the receive area in bytes(even if DB).	RLEN	R	W
STYP	Data type of the send mailbox: 'D' = DB 'X' = DX 'M' = flag 'E' = input 'A' = output	STYP	R	w
SDBN	If STYP DB or DX block number otherwise no use.	SDBN	R	W
SBEG	Beginning of the send mailbox. If DB and DX is starting - data word, or start - data byte.	SBEG	R	W
SLEN	Length of the send mailbox in bytes (even if DB).	SLEN	R	W
TxLEN	Number of bytes to be sent.	LEN	R	W

	.pe Söllnerstr. 9 _ 92637 Weiden _ info@traeger.de _ +49 (0)961 48 23 0 0			ENTS	
Designation	Meaning	FB - parameter	Access R = read W = write		
			S5 - GW	PLC	
Tx <b>STAT</b>	Send Status evaluate if DONE or ERR is set to 1. If DONE is 1 the contract was executed without error. STAT is 0	STAT	W	R	
Tx <b>ACT</b>	Start a send job in S5 - LAN.	ACT	R/W	R/W	
Tx <b>ERR</b>	Is 1 if an error has occurred. The error can be seen in detail the STAT field.	ERR	W	R/W	
TxDONE	Is 1 if the job was executed successfully end.	DONE	W	R/W	
RxLEN	Number of bytes that have been received.	LEN	W	R	
Rx <b>STAT</b>	Reception status once when DONE or ERR is set to 1. If DONE is 1 the order was executed without error. STAT is 0	STAT	W	R	
Rx <b>ACT</b>	Enables the receive mailbox if 1.	ACT	R/W	R/W	
Rx <b>ERR</b>	Is 1, when an error has occurred. The error can be seen in detail the STAT field.	ERR	W	R/W	
NDR	Is 1 if data has been received (data received). RxLEN then evaluate.	NDR	W	R/W	

It is provided for an easy communication which the FB55 (S5L SEND) and FB56 (S5L RECV). In these modules is set the communication between S5 - Gateway and PLC. The FBs was developed in dependence with the S5 - communication FC's (FC5, FC6, AG - SEND or AG - RECV).

NOTE: These devices use 200 MW and 202 MW as scratchpad flag area.

## 10.2 S5 to S7 – Gateway Communickation

### 10.2.1 S5 – Configuring Gateway

Requirements: S5-LAN Manager

Supported since firmware version 0.44 of the S5 - Gateway.

1. Start the S5-LAN Manager and search for your S5 - Gateway module. As soon as found, select it and click on the button "S5 - Gateway - connection". It appears a dialog where you can set up the gateway connection.

TRAEGER DE

TRAEGER.DE Söllnerstr. 9 92637 Weiden info@traeger.de +49 (0)961 48 23 0 0						
ō-Gateway Conne	ctions					×
No.of	1					
Name:	Example					
Configuration-DB:	1 from 0					
Type of	ISO-on-TCP connecti	on	✓ □ Ac	tive connecti	on	
Poll cycle:	0 ms					
Addresses	·					
loc	al		Part	ner		
IP-Address 192	2.168.2.103		1	92 . 168 .	2 . 101	
Port 0			0			
TSAP (ASC) Ur	nique		Uni	que		
TSAP-Lenghi 6			6			
Nr Name	Typ aktiv	P-Zyklus	Konfig-DB	IP-Partner	Port Lokal	Po
1 Exam	ISO on	0	DB1.DBW0	192.168	0	0
2	150 on	0	DR0'DRM0	0.0.0.0	U	U
<						>
			OK		Cancel	

2. In the lower part of the dialog you will find the connection list where you select the connection you want to edit.

3. At the top of the dialog a edit box called "name:" allows you to give the connection a logical name.

4. Below set up the position of the "configuration data block". Therefore just set the position of the data block (DB) to the left edit box (e.g. "1" for DB1). Then set up the starting point which specifies when the configuration area starts (the edit box is called " from DW").

5. Set the connection type list box (it is called "connection type" in the dialog) to "ISO - on - TCP - connection". This connection type uses the TCP port 102.

6. The polling cycle (ms) specifies the elapsed time until the S5 - Gateway reads the configuration area and checks whether something has to be done. If this box is set to 0, the configuration area will be read constantly.

7. Only the member of the IP address ("Partner") can be set in the address part ("Addresses"). The IP address of the S5 - Gateway you have to set as known by using the S5-LAN Manager.

8. Configure the TSAP (Transport - Service - Access - Point) to both devices. This one consists of 16 characters and identifies the connection. This will be needed to identify a connection to an IP address which has running more than one connections.

9. The communication is compatible to the "ISO - on - TCP - connection" connection of the CP343 - 1. In this case only has to be configured the required connections of the S7 - CP343 - 1. Set the TPDU - size (Transport - Protocol - Data - Unit) to 512. So you have specified that the maximum package size which can be received or transmitted is 512.

Finally the S5 - Gateway communication is set up.

TRAEGER DE



Start your Internet Explorer and type in the address bar the IP of the S7-LAN module. This will open the configuration page of the S7 - LAN.

#### 10.2.2.1 With the web browser

Set in the "General" what should be the name for your module.

Among other things, the "TS function" must be turned off and "BUS - configuration use from PC" must be set to "NO". "Boot Settings" and "protocol type" must both be set to "Automatic".

Algemein	Netzwerk	REC1006	MELEROFIBUS Tuning	Anzeige S7_an_S5/S7_Gateway VarSteuem KonfigVarSt Watchdog Passwort
Betriebssyste	m			V 2.07
Name				Example
TS-Funktion				O EIN @ AUS
BUS-Konfigur	ation vom PC ver	wenden		O JA ⊙ NEIN
Booteinstellun	g			Automašk 🛩
Protokollart				Automatik 🛩
Baudrate (nur	bei Booteinstellu	ng Sonder)		Automatik
Datenbit (nur t	bei Booteinstellur	g Sonder)		8 M
Parität (nur be	i Booteinstellung	Sonder)		Keine of
Stopbit (nur bi	ei Booteinstellung	Sonder)		

Speichem

Under "Network" you must set the "DHCP - client" to "OFF", and adjust the IP - address of the module.

Algemein	Netzwerk	REC1006	MPI/PROFIBUS Tuning	Anzeige S7_an_S5/S7_Gateway VarSteuern KonfigVarSt Watchdog Passwort			
DHCP-Client				O EIN ⊚AUS			
IP-Adresse (be	Adresse (bei kein DHCP-Client oder kein DHCP-Server gefunden)						
Sub-Netzmask	Sub-Netzmaske (bei kein DHCP-Client oder kein DHCP-Server gefunden)						
Gateway-Adre 0.0.0.0 für kein	sse (bei kein DH Gateway	ICP-Client oder ke	in DHCP-Server gefunden)	00.00			

Speichem

Set the baud rate in "MPI / PROFIBUS" on 187K5 and determine the highest station address. Under "Local Station Address" give an number to your S7-LAN. The "profile" must be set to "MPI".

Aligemein	Netzwerk	RFC1006	MPI/PROFIBUS Tuning	Anzeige S7_an_S5/S7_Gateway VarSteuem KonfigVarSt Watchdog Passwort
Baudrate				187K5 👻
höchste Statio	onsadresse			126 💌
lokale Teilneh	meradresse			9
Profil				MPI 💌
stärkere Busa	nschaltung			AUS 🛩

Speichem

The next step is to configure the gateway. Here you have to set "Connection Type", "DB - Active" (the partner device "passive") and in the "Station Number" you must enter the number of your PLC. Now you should decide which of the configuration data block is in your PLC and from which data word. Type in the IP - address of your S5 - LAN in the field "IP - address partner". In "TSAP" your store the same name as you have assigned in the S5 - LAN Manager to your - S5 LAN.

Allgemein	3	Netzwerk	RFC1006	MPVPROFIBUS	Tuning	Anzeige	S7_an_S5/S7_Gateway VarSteuem
Verbindu	ngstyp	o Stationsnummer	Datenbaustein	Datenwort	IP-Adresse Partner	TSAP	Pollzeit
DB-Aktiv	~	5	10	0	192.168.1.54	1234	500
AUS	~	255	65535	65535	255.255.255.255	)[	65535
AUS	*	255	65535	65535	255 255 255 255		65536
AUS	٣	255	65535	65535	255 255 255 255	1	65536
AUS	¥	255	65535	65535	255.255.255.255		65535
AUS	¥	265	65535	05535	265.255.255.255		65535
AUS	*	266	66535	65535	255.255.255.255		65535
AUS	*	255	65535	65535	255.255.255.255	][	66536

#### Speichern

Finally, you still have to enter the number of your CPU that is stored in your PLC about "RFC1006" in "destination - CPU", and the "Bus" should be "Config".





Algemein	Netzwerk	RFC1006	MPI/PROFIBUS Tuning	Anzeige S7_an_S5/S7_Gateway VarSteuern KonfigVarSt Watchdog Passwort
Ziel-CPU				5
S7-Subnetz-ID	F			0000-0000
Busparameter				Konfig 🛩
Zustand				RFC1006 Aktiv
000 Empfangs 000: Sendestal 1 keine TCP/IF 2 keine TCP/IF 3 keine TCP/IF 4 keine TCP/IF 5 keine TCP/IF 6 keine TCP/IF 7 keine TCP/IF	status OK Auftrag an verbindung nice Verbindung nice Verbindung nice Verbindung nice Verbindung nice Verbindung nice Verbindung nice	ausgeführt usgeführt ht im MPLBus ht im MPLBus ht im MPLBus ht im MPLBus ht im MPLBus ht im MPLBus		

Speichem

### 10.2.2.2 With the web browser from V2.10 (S7-LAN) / V2.36 (MPI-LAN)

tartseite	Allgemein								
erbindungen	Name:	Test KM							
ptionen	Werkseinstellungen laden:	Jetzt laden							
onfiguration asswort	- Netzwerk								
eustart	Netzwerk	Netzwein							
	DHCP aktivieren:								
	IP-Adresse:	192.168.1.151							
	Subnetzmaske:	255.255.255.0							
	Gateway-Adresse:	0.0.0.0							
	Buseinstellungen								
	Bus-Konfig von PC verwenden								
	Baudrate:	18765							
	Lincheta Stationeadracea:	120							
	PORC interingent Master								
	Povec ist einziger waster.								
	Pron.	MPI M							
	Lokale Adresse:								
	Booteinstellungen	Booteinstellungen							
	Profil:	Automatik 🗸							
	<b>⊢</b> Für manuelle Profileinste	əllung							
	Baudrate:	Automatik 🛩							
	Datenbit:	8							
	Parität	keine Y							
	Stopbit:								
	- Für REC1006 Verbindunge	5D							
	Tiel CPUI:								
		000000000							
	S7-Subnetz-ID:	0000-0000							
	Busparameter.	Konig							
	Sonstiges								
	Protokollart:	Automatik 💌							
	TS-Adapterfunktionalität:								

Set in the "General" what should be the name for your module.

Under "Network" you must set the "DHCP - client" to "OFF" and adjust the IP - address of the module.

Set the baud rate in "Bus Settings", to 187K5 and determine the highest station address. Under "Local Station Address" you give a number to your S7-LAN. The "profile" must be set to "MPI" and at "BUS - use config from PC" must be set no "tick.

TRAEGER.pe Söllnerstr. 9 . 92637 Weiden . info@traeger.de . +49 (0)961 48 23 0 0

Under "other", the "TS Adapter functionality" must be off. "Boot Settings" and "protocol type" must both be set to "Automatic".

Finally, you still have to enter the number of your CPU that is stored in your PLC about "RFC1006" in "destination - CPU" and the "Bus" should be "Config".

S7-LAN V2.10	Test KM					IP:192.168.1.151		
Startseite     Verbindungen	-Gateway-	Ver	bindungen IP-Adresse	TSAP	Pollzeit	CPU	DB	Datenwort
<ul> <li>Display</li> <li>Ontionen</li> </ul>	DB-Aktiv	×	192.168.1.54	1234	500	5	10	0
Variablen-Steuern	Aus	۷	255.255.255.255		65535	255	65535	65535
<ul> <li>S7-Gateway</li> </ul>	Aus	*	255.255.255.255		65535	255	65535	65535
Watchdog     Konfiguration	Aus	¥	255.255.255.255		65535	255	65535	65535
Passwort	Aus	Y	255.255.255.255		65535	255	65535	65535
Neustart	Aus	×	255.255.255.255		65535	255	65535	65535
	Aus	*	255.255.255.255		65535	255	65535	65535
	Aus	~	255.255.255.255		65535	255	65535	65535

The final step is to configure the gateway. Here you have to set "Connection Type", "DB - Active" (the partner device "passive") and at "Station Number" you have to enter the number of your PLC. Now you should decide which is the configuration data blocks in your PLC and from which data word. Type in the IP - address of your S5 - LAN in the field "IP - address partner". In "TSAP" your store the same name as you have assigned in the S5 - LAN Manager to your - S5 LAN.

### 10.2.3 Transfer blocks in PLC

1. Start your programming software and open the S5D - file "S5toS5 - Gateway".

2. Now connect with your S5 - Gateway modules and transfer all the blocks (OB1, FB55 and FB56) in the module belonging to the PLC. The same blocks you now even transfer into the second PLC. The blocks DB20 and DB100 are generated by itself.

3. Now open the S7P - file "S5toS7 - Gateway".

4. Now connect with your S7 - LAN module and transfer the blocks (OB1, FB10, FC15, FC16, DB10 and DB14) into the PLC

### 10.2.4 Start transmission cycle

#### S5 controller

In the following example, the DB20 is used as configuration - DB. M10.0 controls the sending and M12.0 controls the receiving. If M10.0 is "1", then 20 bytes of the DB100 are sent from the DW0. M12.0 the receive mailbox DB100 gives free 20 bytes from DW100.

	:	SPA	FB	55
name	:	S5L_SEND JDBN		
	:		KF	+00020
JDBW	:		KF	+00000
STYP	:		KC	D
SDBN	:		KF	+00100
SBEG	:		KF	+00000



SLEN	:		KF	+00020
ACT	:		М	10.0
LEN	:		KF	+00020
DONE	:		М	11.0
ERR	:		М	11.1
STAT	:		MW	20
	:			
	:	SPA	FB	56
Name	:	S5L_RECV		
JDBN	:		KF	+00020
JDBW	:		KF	+00000
RTYP	:		KC	D
RDBN	:		KF	+00100
RBEG	:		KF	+00100
RLEN	:		KF	+00020
ACT	:		М	12.0
LEN	:		MW	24
NDR	:		М	13.0
ERR	:		М	13.1
STAT	:		MW	22

Set the inputs E8.0 and E9.0 to "1" for sending and receiving.

#### **S7 controller**

In the following example, the DB10 is used as DB configuration. M10.0 controls the sending and M11.0 controls the receiving. If M10.0 is "1", then 20 bytes of the DB14 are sent from DW0. M11.0 the receive mailbox DB14 gives free 20 bytes from DW100.

CALL "S7LAN	_SE	ND"	
KOMDB	:	=	"S7LAN Communication DB".KOM
SENDTYPE	:	=	'D'
SENDDB	:	=	14
SENDADR	:	=	0
SENDLEN	:	=	20
ACT	:	=	M10.0
LEN	:	=	20
DONE	:	=	M10.1
ERROR	:	=	M10.2
STATUS	:	=	MW12
CALL "S7LAN	_RE	CV"	
KOMDB	:	=	"S7LAN Communication DB".KOM
RECVTYPE	:	=	'D'
RECVDB	:	=	14
RECVADR	:	=	100
RECVLEN	:	=	20
ACT	:	=	M11.0
NDR	:	=	M11.1
ERROR	:	=	M11.2
STATUS	:	=	MW14



LEN

: = MW16

### 10.2.5 Test of the structure

1. Open the each DB100 in your PLCs and enter any values in the first 20 bytes. \\e.g.:(1; 2; 3; 4; 5; 6; 7; 8; 9)

🔼 DB	100	- C:\DOKU	MENTE L	IND EINSTELLU	INGEN\\S	5ANS5-GATE	WAY\S5	ANS5			×
								Bib	=		^
	0:	KH =	0001;								
	1:	KH =	0002;								-
	2:	KH =	0003;								
	3:	KH =	0004;								
	4:	KH =	0005;								
	5:	KH =	0006 ;								
	6:	KH =	0007;								
	7:	KH =	0008;								
	8:	KH =	0009;								
	9:	KH =	0000;								
1	0:	KH =	0000;								
1	1:	KH =	0000;								
1	2:	KH =	0000;								
1	3:	KH =	0000;								
1	4:	KH =	0000;								
1	5:	KH =	0000;								
1	6:	KH =	0000;								
1	7:	KH =	0000;								~
<										>	

2. Save the blocks and set the inputs E8.0 and E9.0 to "1" in your PLC with the active S5 - Gateway module and restart the cycle.

■ STI	EU	ERN VARIA	BLE		
Mark	1	Adresse	Art	Wert	Kommentar
-	E	8.0	KM	1	
•	E	9.0	KM	1	
<					

3. Now open the DB100 and check whether the values of the 20 bytes which you have configured in the other PLC in DB100 match with those from DW100.

🖾 DB 100	- C:\DOKUMENTE UN	ID EINSTELLUNGEN\\S5ANS5-GATEWAY\S5ANS5 🔳 🗖 🔀
97:	KH = 0000;	A
98:	KH = 0000;	
99:	KH = 0000;	
100:	KH = 0001;	
101:	KH = 0002;	
102:	KH = 0003;	
103:	KH = 0004;	
104:	KH = 0005;	
105:	KH = 0006;	
106:	KH = 0007;	
107:	KH = 0008;	
108:	KH = 0009;	
109:	KH = 0000;	
110:	KH = 0000;	
111:	KH = 0000;	
112:	KH = 0000;	
113:	KH = 0000;	
114:	KH = 0000;	
115:	KH = 0000;	
<		

If they match, the communication was successful.



TRAEGER.DE Söllnerstr. 9 . 92637 Weiden . info@traeger.de . +49 (0)961 48 23 0 0

4. Open the DB14 in your S7 - PLC and enter any values in the first 20 bytes.

#### e.g.: (1; 2; 3; 4; 5; 6; 7; 8; 9; 10)

		10 00 22 52			
resse	Nane	Typ	(Listen) ingaver	Aktualwert	Rosmentar
0,0	SIATO[1]	WORD	W#16#0	X#16#1	
2.0	STAT0[2]	NORD	Nelded	X#16#2	
	SIA10[3]	NORD	N#16#C	X#16#3	
6.1	STATO[4]	D80W	8#18#0	N#16#4	
4.9	51A10[5]	NORD	10#16#0	N#16#5	
10,0	31310[6]	W082	W#16#0	X#16#6	
12.0	STATO[7]	NURC	N#16#0	N#18#7	
14.5	STAIO(8)	WUSD I	N#16#0	X#16#8	
18.0	stato(a)	8080	841040	n#16#3	
10.0	21410[10]	NURD	N#16#0	A#16#10	
20,0	SIAIO[11]	WORLD .	N#2C#C	001500	
22.0	51810[12]	NURC	NELGEO	N#10#U	
64.5	STM10[19]	NUSG 10000	N#10#5	N#10#V	
20.1	STATO[14]	19530	N#10#0	N#10#U	
40.4	D1A10[15]	10000	N#10#V	N#10#0	
2212	31410[16]	WUSD2	N#LC#U	041240	
34.5	Disto[1]	17525	N#10#0	N#10#U	
	00374(140)	tungin.	1041-240	Malcan	
10 1	STATO[12]	waca.	1041.541	201500	
10.0	GTATATOLSVI	10000	201240	Walcan	
13.1	PERIOLES]	WARE .	Wat san	Wet Sed	
44.0	STATO (DAL	singn.	Wat dag	201640	
26.1	87376(94)	10100	1041.645	Wat 6a0	
45.0	STATO (251	10020	Welsen	2001 500	
84.4	97370(24)	100875	We1 640	241640	
52 /	STATO(27)	NORD	Welded	X#16#0	
54.0	STATO(281	WOSD	N#14#0	Xelfed	
56.0	87370(29)	Woab	Net Set	Nel 6e0	
55.0	STATO (30)	NOSO	Welsed	2001600	
60.0	STAT0[311	1080	1941540	2041640	
	need a family	0.000			2
	Resten in Zeleur	1477.			(D BUILD Tots Lot

Mark		Adresse	Art	Wert	Kommentar
	E	8.0	KM	1	
•	E	9.0	KM	1	
<					

6. Open the DB14 in your S7 - PLC and check if the values of the 20 bytes which you configured in the other PLC in DB100 and DB14 from DW0 match with those from DW100. If that is the case, the communication between S5 and S7 was successfully performed.

PAWL/FUP IDB14	Erreichbare Teilneb	mer MPI - 5 (direkt	A CALINET	
el Bearbeiten Einfugen	Zielsystem Test Ansicht	Extras Fenster Hilfe		-
electroles letter				
212-1 <b>2</b>   <b>3</b>   X   0-		0 6 KM		
04.0 STAT0(43)	WORD	Welden Welden		<b>A</b>
86.0 STAT0[44]	WORD W	1640 Wel640		
88.0 STATO[45]	NORD 10	0+3142 0+314		
90.0 STAT0[46]	WORD W	Waleao Naleao		
92.0 STAT0[47]	WORD W	W#16#0 N#16#0		
94.0 STATO (40)	WORD W	Welced Welced		
96.0 STAT0 [49]	WORD W	W#16#0 W#16#0		
98.0 STATO (50)	WORD W	1041640 N041640		
00.0 STAT0[51]	WORD W	Walead Waleal		
02.0 STATO (52)	NORD W	1640 N+16+2		
04.0 STAI0(33)	WORD X	W#16#0 17#16#3		
06.0 STAT0 (54)	WORD CROW	W#16#0 N#16#4		
08.0 STAT0[55]	WORD W	1640 N41645		
10.0 STAT0[56]	WORD	W#16#D N#16#6		
12.0 STAT0[57]	NORD X	1640 N#1647		
14.0 STAT0[58]	NOBD W	W#16#0 W#16#8		
6.0 STAT0(59)	WCRD CROW	W#16#0 N#16#9		
0.0 STAT0[60]	WORD W	1640 Neldelo		
0.0 STAT0[61]	WORD W	W#16#0 N#16#0		
22.0 STAT0[62]	NORD W	1640 Ne1640		1
24.0 STAT0[63]	WORD W	Weleeg		
26.0 STATO [64]	NORD CROW	1#16#0 N#16#0		
18.0 STATO (45)	WORD W	Walead Walead		
30.0 STAT0[66]	WORD W	W#16#0 W#16#0		
32.0 STATO(67)	NORD X	161640 Nel6e0		
34.0 STATO[68]	WORD W	W#16#0 W#16#0		
36.0 STATO(69)	NORD K	Welded Nelded		
38.0 STAT0[70]	WORD X	W#16#0 W#16#0		
40.0 STAT0[71]	W CROW	W#16#0 N#16#0		
42.0 STAT0 [72]	100RD 10	Meldeo Meldeo		
44.0 STAT0[73]	WORD W	Wel6e0 Nel6e0	2	
46.0 STATO [74]	NORD N	0+31+X 0+31+0		<i>u</i>

The bytes from DW100 should be the same as the ones you have configured in the DB100 S5 - PLC from DW0.

If they match, the communication was successful







### Table of Contents

S5-LAN++	
2.1 Operating System(s)	2
2.2 Software	2
2.3 Hardware	2
2.4 Supported controls	3
2.5 Possible problems while commissioning of the module	3
4.1 Hardware	4
4.2 Software	4
4.2.1 Installation and usage of S5-LAN++-module under Win98	5
4.2.2 Installation of the Step5 $\ensuremath{\mathbb{C}}$ addition driver for PG-USB/S5-LAN + + / USB-RS232-conve	rter
	6
5.1 LEDs and reset	8
6.1 Initial configuration	8
6.2 Using the PLC-VCOM	10
6.3 Programming software to use with direct access	10
6.3.1 S7-TCP/IP to S5-LAN++	10
6.3.2 PG2000 für S5 (V5.10)	12
6.3.3 SIMATIC Step <sup>©</sup> 5 Manager	14
6.3.4 Windows Control Center (WinCC) (v6.0)	15
6.3.5 Direct communication with WinCC 6.0	17
6.3.6 Windows Control Center flexible 2004 (WinCC flexibel) (v5.2.0.0)	19
6.3.7 Communication WinCC flexible with S5-LAN++	21
6.3.8 ProTool/Pro v6.0 SP2	23
6.3.9 S5 for Windows v5.02	25
6.3.10 S5-gateway communication (coupling)	27
6.3.10.1 Technical information for the configuration area	29
6.3.11 TIA-Portal	31
7.1 S5-LAN Manager	32
7.1.1 Ports	34
8.1 Description	
8.2 Installation	35
8.2.1 Final configuration of the PLC-VCOM	35
8.3 Overview	35
8.3.1 Status description:	35
8.3.2 Main Window	36
8.3.3 Configuration window	37
8.4 Configuration	38
8.4.1 S5-LAN / S5-LAN++	38
8.4.1.1 Automatically	38
8.4.1.2 Manual	38
8.4.1.3 Final settings	39
8.4.2 S5-Gateway / S5-Gateway+	39
8.4.2.1 Automatically	40
8.4.2.2 Manual	40
8.4.2.3 Final settings	40
9.1 pin assignment power supply	41
9.2 Pinning Ethernet	41
9.3 Pin assignment TTY / 20mA current loop	41
9.4 Pin assignment RS232 (for special-S5-LAN + + variant-RS)	42
10.1 S5 to S5 - Gateway communication	42
10.1.1 Configuration S5 gateway	42