

PlcLRealArray Class

Namespace: IPS7Lnk.Advanced

Assemblies: IPS7LnkNet.Advanced.dll

Represents a PLC array which addresses an unique data entry stored within a programmable logic controller (PLC) its values are double-precision floating-point numbers ([Double](#)).

C#

```
public class PlcLRealArray : PlcArray<double, PlcLReal>, IPlcArray<double, PlcLReal>,
    IPlcValue<double[]>, IPlcArray, IPlcValue, IPlcSymbol, IPlcEntity, IPlcStatusProvider,
    IPlcRelocatable<IPlcValue>, IPlcRelocatable, ISupportInitialize, IEnumerable<double>,
    IEnumerable
```

Inheritance [Object](#) > [PlcValue<Double>](#) > [PlcArray<Double, PlcLReal>](#) > [PlcLRealArray](#)

Implements [IPlcArray<Double, PlcLReal>](#), [IPlcValue<Double>](#), [IPlcArray](#), [IPlcValue](#), [IPlcSymbol](#), [IPlcEntity](#), [IPlcStatusProvider](#), [IPlcRelocatable<IPlcValue>](#), [IPlcRelocatable](#), [ISupportInitialize](#), [IEnumerable<Double>](#), [IEnumerable](#)

Remarks

While a PLC array of this type represents an array of [Double](#) values, all PLC operations performed using this class are done using the [LWord](#). A PLC developer knows an array of this type as an ARRAY OF LREAL.

Constructors

Name	Description
PlcLRealArray(PlcIdentity, Double)	Initializes a new instance of the PlcLRealArray class using the specified identity and values .
PlcLRealArray(PlcIdentity, Int32)	Initializes a new instance of the PlcLRealArray class using the specified identity and length .
PlcLRealArray(PlcIdentity, PlcName, Double)	Initializes a new instance of the PlcLRealArray class using the specified identity , name and values .
PlcLRealArray(PlcIdentity, PlcName, Int32)	Initializes a new instance of the PlcLRealArray class using the specified identity , name and length .
PlcLRealArray(PlcLRealArrayType)	Initializes a new instance of the PlcLRealArray class using the specified type .
PlcLRealArray(PlcLRealArrayType, Double)	Initializes a new instance of the PlcLRealArray class using the specified type and values .
PlcLRealArray(PlcLRealArrayType, PlcName, Double)	Initializes a new instance of the PlcLRealArray class using the specified type , name and values .

Methods

Name	Description
GetElementCore(Int32)	Retrieves the PlcLReal at the specified index.

Name	Description
<code>GetValueCore(PlcDeviceConnection)</code>	Retrieves the current value of the PLC value from a <code>IPlcDevice</code> using the <code>connection</code> specified.
<code>RelocateCore(PlcAddress)</code>	Relocates the value to the <code>address</code> specified.
<code>SetValueCore(PlcDeviceConnection, Double)</code>	Stores the <code>value</code> in the <code>IPlcDevice</code> assigned to the <code>connection</code> specified.

Table of Contents

Remarks	1
Constructors	1
Methods	1

