OPC UA SDK
Client + Server Development

Core API

Read Service

The types in this section are used to invoke the service used to read data. These data is restricted to attributes only. Not all attributes available can be read at any time and not on any type of node. Use the components in this section to control the service invocation according to the data requested.

- OpcReadNode
- OpcReadNodeCollection

Table of Contents

Read Service 1