PlcDoubleArray Members

Namespace: IPS7Lnk.Advanced
Assemblies: IPS7LnkNet.Advanced.dll, IPS7LnkNet.Advanced.dll
The PlcDoubleArray type exposes the following members.

Constructors

PlcDoubleArray(PlcDoubleArrayType)

Initializes a new instance of the PlcDoubleArray class using the specified `type`.

C#

```
public PlcDoubleArray(PlcDoubleArrayType type)
```

Parameters

`type` PlcDoubleArrayType

The PlcDoubleArrayType of the new PlcDoubleArray to which the PLC array belongs.

Exceptions

ArgumentNullException

The `type` is a null reference (Nothing in Visual Basic).

PlcDoubleArray(PlcDoubleArrayType, Double[])

Initializes a new instance of the PlcDoubleArray class using the specified `type` and `values`.

C#

```
public PlcDoubleArray(PlcDoubleArrayType type, params double[] values)
```

Parameters

`type` PlcDoubleArrayType

The PlcDoubleArrayType of the new PlcDoubleArray to which the PLC array belongs.

`values` Double[]

The initial values of the new PlcDoubleArray.

Exceptions

ArgumentNullException

The `type` is a null reference (Nothing in Visual Basic).

PlcDoubleArray(PlcDoubleArrayType, PlcName, Double[])

Initializes a new instance of the PlcDoubleArray class using the specified `type`, `name` and `values`.

C#

```
public PlcDoubleArray(PlcDoubleArrayType type, PlcName name, params double[] values)
```

Parameters

`type` PlcDoubleArrayType

The PlcDoubleArrayType of the new PlcDoubleArray to which the PLC array belongs.

`name` PlcName

The name of the array represented.

`values` Double[]

The initial values of the new PlcDoubleArray.

Exceptions

ArgumentNullException

The `type` or `name` is a null reference (Nothing in Visual Basic).

PlcDoubleArray(PlcIdentity, Double[])

Initializes a new instance of the PlcDoubleArray class using the specified `identity` and `values`.

C#

```
public PlcDoubleArray(PlcIdentity identity, params double[] values)
```

Parameters

`identity` PlcIdentity

The PlcIdentity of the new PlcDoubleArray to which the PLC array belongs.

`values` Double[]

The initial values of the new PlcDoubleArray.

Exceptions

ArgumentException

The `identity` does not refer to the DWord.

ArgumentNullException

The `identity` is a null reference (Nothing in Visual Basic).

PlcDoubleArray(PlcIdentity, Int32)

Initializes a new instance of the PlcDoubleArray class using the specified `identity` and `length`.

C#

```
public PlcDoubleArray(PlcIdentity identity, int length)
```

Parameters

`identity` PlcIdentity

The PlcIdentity of the new PlcDoubleArray to which the PLC array belongs.

`length` Int32

The array length used to store the array values of the PlcDoubleArray.

Exceptions

ArgumentException

The `identity` does not refer to the DWord.

ArgumentNullException

The `identity` is a null reference (Nothing in Visual Basic).

ArgumentOutOfRangeException

The `length` is out of the bounds defined by MinLength and MaxLength.

PlcDoubleArray(PlcIdentity, PlcName, Double[])

Initializes a new instance of the PlcDoubleArray class using the specified `identity`, `name` and `values`.

C#

```
public PlcDoubleArray(PlcIdentity identity, PlcName name, params double[] values)
```

Parameters

`identity` PlcIdentity

The PlcIdentity of the new PlcDoubleArray to which the PLC array belongs.

`name` PlcName

The name of the array represented.

`values` Double[]

The initial values of the new PlcDoubleArray.

Exceptions

ArgumentException

The `identity` does not refer to the DWord.

ArgumentNullException

The `identity` or `name` is a null reference (Nothing in Visual Basic).

PlcDoubleArray(PlcIdentity, PlcName, Int32)

Initializes a new instance of the PlcDoubleArray class using the specified `identity`, `name` and `length`.

C#

```
public PlcDoubleArray(PlcIdentity identity, PlcName name, int length)
```

Parameters

`identity` PlcIdentity

The PlcIdentity of the new PlcDoubleArray to which the PLC array belongs.

`name` PlcName

The name of the array represented.

`length` Int32

The array length used to store the array values of the PlcDoubleArray.

Exceptions

ArgumentException

The `identity` does not refer to the DWord.

ArgumentNullException

The `identity` or `name` is a null reference (Nothing in Visual Basic).

ArgumentOutOfRangeException

The `length` is out of the bounds defined by MinLength and MaxLength.

Methods

GetElementCore(Int32)

Retrieves the PlcDouble at the specified index.

C#

```
protected override PlcDouble GetElementCore(int index)
```

Parameters

`index` Int32

The zero-based index of the element to get.

Returns

PlcDouble

The PlcDouble at the specified index.

GetValueCore(PlcDeviceConnection)

Retrieves the current value of the PLC value from a IPlcDevice using the `connection` specified.

C#

```
protected override double[] GetValueCore(PlcDeviceConnection connection)
```

Parameters

`connection` PlcDeviceConnection

The PlcDeviceConnection from that the data is to be retrieved.

Returns

Double[]

The current value of the PLC value.

Exceptions

InvalidOperationException

The `connection` is in Faulted state and cannot longer be opened.

ObjectDisposedException

The `connection` has been disposed of.

RelocateCore(PlcAddress)

Relocates the value to the `address` specified.

C#

```
protected override IPlcValue RelocateCore(PlcAddress address)
```

Parameters

`address` PlcAddress

The PlcAddress to that the value is to be relocated.

Returns

IPlcValue

A new instance of the same type as this PLC value instance relocated to the `address` specified.

SetValueCore(PlcDeviceConnection, Double[])

Stores the `value` in the IPlcDevice assigned to the `connection` specified.

C#

```
protected override void SetValueCore(PlcDeviceConnection connection, double[] value)
```

Parameters

`connection` PlcDeviceConnection

The PlcDeviceConnection to use to store the `value`.

`value` Double[]

The value to be stored.

Exceptions

InvalidOperationException

The `connection` is in Faulted state and cannot longer be opened.

ObjectDisposedException

The `connection` has been disposed of.

Table of Contents

Constructors 1
PlcDoubleArray(PlcDoubleArrayType) 1
PlcDoubleArray(PlcDoubleArrayType, Double[]) 1
PlcDoubleArray(PlcDoubleArrayType, PlcName, Double[]) 2
PlcDoubleArray(PlcIdentity, Double[]) 2
PlcDoubleArray(PlcIdentity, Int32) 3
PlcDoubleArray(PlcIdentity, PlcName, Double[]) 3
PlcDoubleArray(PlcIdentity, PlcName, Int32) 4
Methods 4
GetElementCore(Int32) 4
GetValueCore(PlcDeviceConnection) 5
RelocateCore(PlcAddress) 5
SetValueCore(PlcDeviceConnection, Double[]) 6