PlcUInt16 Members

Namespace: IPS7Lnk.Advanced
Assemblies: IPS7LnkNet.Advanced.dll, IPS7LnkNet.Advanced.dll
The PlcUInt16 type exposes the following members.

Constructors

PlcUInt16(PlcIdentity)

Initializes a new instance of the PlcUInt16 class using the specified `identity`

C#

```
public PlcUInt16(PlcIdentity identity)
```

Parameters

`identity` PlcIdentity

The PlcIdentity of the new PlcUInt16 to which the PLC value belongs.

Exceptions

ArgumentException

The `identity` does not refer to the Word.

ArgumentNullException

The `identity` is a null reference (Nothing in Visual Basic).

PlcUInt16(PlcIdentity, PlcName)

Initializes a new instance of the PlcUInt16 class using the specified `identity` and `name`.

C#

```
public PlcUInt16(PlcIdentity identity, PlcName name)
```

Parameters

`identity` PlcIdentity

The PlcIdentity of the new PlcUInt16 to which the PLC value belongs.

`name` PlcName

The name of the value.

Exceptions

ArgumentException

The `identity` does not refer to the Word.

ArgumentNullException

The `identity` or `name` is a null reference (Nothing in Visual Basic).

PlcUInt16(PlcIdentity, PlcName, UInt16)

Initializes a new instance of the PlcUInt16 class using the specified `identity`, `name` and `value`.

C#

```
public PlcUInt16(PlcIdentity identity, PlcName name, ushort value)
```

Parameters

`identity` PlcIdentity

The PlcIdentity of the new PlcUInt16 to which the PLC value belongs.

`name` PlcName

The name of the value.

`value` UInt16

The initial value of the new PlcUInt16.

Exceptions

ArgumentException

The `identity` does not refer to the Word.

ArgumentNullException

The `identity` or `name` is a null reference (Nothing in Visual Basic).

PlcUInt16(PlcIdentity, UInt16)

Initializes a new instance of the PlcUInt16 class using the specified `identity` and `value`.

C#

```
public PlcUInt16(PlcIdentity identity, ushort value)
```

Parameters

`identity` PlcIdentity

The PlcIdentity of the new PlcUInt16 to which the PLC value belongs.

`value` UInt16

The initial value of the new PlcUInt16.

Exceptions

ArgumentException

The `identity` does not refer to the Word.

ArgumentNullException

The `identity` is a null reference (Nothing in Visual Basic).

PlcUInt16(PlcUInt16Type)

Initializes a new instance of the PlcUInt16 class using the specified `type`

C#

```
public PlcUInt16(PlcUInt16Type type)
```

Parameters

`type` PlcUInt16Type

The PlcUInt16Type of the new PlcUInt16 to which the PLC value belongs.

Exceptions

ArgumentNullException

The `type` is a null reference (Nothing in Visual Basic).

PlcUInt16(PlcUInt16Type, PlcName)

Initializes a new instance of the PlcUInt16 class using the specified `type` and `name`.

C#

```
public PlcUInt16(PlcUInt16Type type, PlcName name)
```

Parameters

`type` PlcUInt16Type

The PlcUInt16Type of the new PlcUInt16 to which the PLC value belongs.

`name` PlcName

The name of the value.

Exceptions

ArgumentNullException

The `type` or `name` is a null reference (Nothing in Visual Basic).

PlcUInt16(PlcUInt16Type, PlcName, UInt16)

Initializes a new instance of the PlcUInt16 class using the specified `type`, `name` and `value`.

C#

```
public PlcUInt16(PlcUInt16Type type, PlcName name, ushort value)
```

Parameters

`type` PlcUInt16Type

The PlcUInt16Type of the new PlcUInt16 to which the PLC value belongs.

`name` PlcName

The name of the value.

`value` UInt16

The initial value of the new PlcUInt16.

Exceptions

ArgumentNullException

The `type` or `name` is a null reference (Nothing in Visual Basic).

PlcUInt16(PlcUInt16Type, UInt16)

Initializes a new instance of the PlcUInt16 class using the specified `type` and `value`.

C#

```
public PlcUInt16(PlcUInt16Type type, ushort value)
```

Parameters

`type` PlcUInt16Type

The PlcUInt16Type of the new PlcUInt16 to which the PLC value belongs.

`value` UInt16

The initial value of the new PlcUInt16.

Exceptions

ArgumentNullException

The `type` is a null reference (Nothing in Visual Basic).

Methods

GetValueCore(PlcDeviceConnection)

Retrieves the current value of the PLC value from a IPlcDevice using the `connection` specified.

C#

```
protected override ushort GetValueCore(PlcDeviceConnection connection)
```

Parameters

`connection` PlcDeviceConnection

The PlcDeviceConnection from that the data is to be retrieved.

Returns

UInt16

The current value of the PLC value.

Exceptions

InvalidOperationException

The `connection` is in Faulted state and cannot longer be opened.

ObjectDisposedException

The `connection` has been disposed of.

RelocateCore(PlcAddress)

Relocates the value to the `address` specified.

C#

```
protected override IPlcValue RelocateCore(PlcAddress address)
```

Parameters

`address` PlcAddress

The PlcAddress to that the value is to be relocated.

Returns

IPlcValue

A new instance of the same type as this PLC value instance relocated to the `address` specified.

SetValueCore(PlcDeviceConnection, UInt16)

Stores the `value` in the IPlcDevice assigned to the `connection` specified.

C#

```
protected override void SetValueCore(PlcDeviceConnection connection, ushort value)
```

Parameters

`connection` PlcDeviceConnection

The PlcDeviceConnection to use to store the `value`.

`value` UInt16

The value to be stored.

Exceptions

InvalidOperationException

The `connection` is in Faulted state and cannot longer be opened.

ObjectDisposedException

The `connection` has been disposed of.

Table of Contents

Constructors 1
PlcUInt16(PlcIdentity) 1
PlcUInt16(PlcIdentity, PlcName) 1
PlcUInt16(PlcIdentity, PlcName, UInt16) 2
PlcUInt16(PlcIdentity, UInt16) 2
PlcUInt16(PlcUInt16Type) 3
PlcUInt16(PlcUInt16Type, PlcName) 3
PlcUInt16(PlcUInt16Type, PlcName, UInt16) 4
PlcUInt16(PlcUInt16Type, UInt16) 4
Methods 5
GetValueCore(PlcDeviceConnection) 5
RelocateCore(PlcAddress) 5
SetValueCore(PlcDeviceConnection, UInt16) 6