



Core API - Address Space

Values

The use of values is to transport information. This information is primarily data. The kind of value depends on the kind of data being transported and may include only raw, live, modified or historically stored data. Independent from which data is transported it is always related to a **Value** attribute.

- [OpcValue](#)
- [OpcValueCollection](#)
- [OpcHistoryValue](#)
- [OpcHistoryModificationInfo](#)
- [OpcModifiedHistoryValue](#)
- [IOpcNodeValue](#)
- [OpcNodeValuePair](#)

Table of Contents

Values	1
---------------------	---