

PlcMemberAttribute Class

Namespace: IPS7Lnk.Advanced

Assemblies: IPS7LnkNet.Advanced.dll

Specifies that a particular class member is to be used as a [PlcMember](#).

C#

```
[AttributeUsage(AttributeTargets.Property | AttributeTargets.Field, AllowMultiple = false)]  
public class PlcMemberAttribute : Attribute, _Attribute
```

Inheritance [Object](#) > [Attribute](#) > PlcMemberAttribute

Attributes [AttributeUsageAttribute](#)

Implements [InteropServices._Attribute](#)

Constructors

Name	Description
PlcMemberAttribute(PlcAddress)	Initializes a new instance of the PlcMemberAttribute class using the address .
PlcMemberAttribute(String)	Initializes a new instance of the PlcMemberAttribute class using the specified address .

Properties

Name	Description
Address	Gets the address associated with the PlcMember .
CanRead	Gets or sets a value indicating whether the member can be read.
CanWrite	Gets or sets a value indicating whether the member can be written to.
Length	Gets or sets the maximum length of the value that can be assigned to the PlcMember .

Table of Contents

Constructors	1
Properties	1