

PlcUInt32Array Members

Namespace: IPS7Lnk.Advanced

Assemblies: IPS7LnkNet.Advanced.dll, IPS7LnkNet.Advanced.dll

The [PlcUInt32Array](#) type exposes the following members.

Constructors

PlcUInt32Array(PlcIdentity, Int32)

Initializes a new instance of the [PlcUInt32Array](#) class using the specified [identity](#) and [length](#).

C#

```
public PlcUInt32Array(PlcIdentity identity, int length)
```

Parameters

[identity](#) [PlcIdentity](#)

The [PlcIdentity](#) of the new [PlcUInt32Array](#) to which the PLC array belongs.

[length](#) [Int32](#)

The array length used to store the array values of the [PlcUInt32Array](#).

Exceptions

[ArgumentException](#)

The [identity](#) does not refer to the [DWord](#).

[ArgumentNullException](#)

The [identity](#) is a null reference (Nothing in Visual Basic).

[ArgumentOutOfRangeException](#)

The [length](#) is out of the bounds defined by [MinLength](#) and [MaxLength](#).

PlcUInt32Array(PlcIdentity, PlcName, Int32)

Initializes a new instance of the [PlcUInt32Array](#) class using the specified [identity](#), [name](#) and [length](#).

C#

```
public PlcUInt32Array(PlcIdentity identity, PlcName name, int length)
```

Parameters

[identity](#) [PlcIdentity](#)

The `PlcIdentity` of the new `PlcUInt32Array` to which the PLC array belongs.

`name` `PlcName`

The name of the array represented.

`length` `Int32`

The array length used to store the array values of the `PlcUInt32Array`.

Exceptions

`ArgumentException`

The `identity` does not refer to the `DWord`.

`ArgumentNullException`

The `identity` or `name` is a null reference (Nothing in Visual Basic).

`ArgumentOutOfRangeException`

The `length` is out of the bounds defined by `MinLength` and `MaxLength`.

PlcUInt32Array(PlcIdentity, PlcName, UInt32[])

Initializes a new instance of the `PlcUInt32Array` class using the specified `identity`, `name` and `values`.

C#

```
public PlcUInt32Array(PlcIdentity identity, PlcName name, params uint[] values)
```

Parameters

`identity` `PlcIdentity`

The `PlcIdentity` of the new `PlcUInt32Array` to which the PLC array belongs.

`name` `PlcName`

The name of the array represented.

`values` `UInt32[]`

The initial values of the new `PlcUInt32Array`.

Exceptions

`ArgumentException`

The `identity` does not refer to the `DWord`.

`ArgumentNullException`

The `identity` or `name` is a null reference (Nothing in Visual Basic).

PlcUInt32Array(PlcIdentity, UInt32[])

Initializes a new instance of the [PlcUInt32Array](#) class using the specified [identity](#) and [values](#).

C#

```
public PlcUInt32Array(PlcIdentity identity, params uint[] values)
```

Parameters

[identity](#) [PlcIdentity](#)

The [PlcIdentity](#) of the new [PlcUInt32Array](#) to which the PLC array belongs.

[values](#) [UInt32\[\]](#)

The initial values of the new [PlcUInt32Array](#).

Exceptions

[ArgumentException](#)

The [identity](#) does not refer to the [DWord](#).

[ArgumentNullException](#)

The [identity](#) is a null reference (Nothing in Visual Basic).

PlcUInt32Array(PlcUInt32ArrayType)

Initializes a new instance of the [PlcUInt32Array](#) class using the specified [type](#).

C#

```
public PlcUInt32Array(PlcUInt32ArrayType type)
```

Parameters

[type](#) [PlcUInt32ArrayType](#)

The [PlcUInt32ArrayType](#) of the new [PlcUInt32Array](#) to which the PLC array belongs.

Exceptions

[ArgumentNullException](#)

The [type](#) is a null reference (Nothing in Visual Basic).

PlcUInt32Array(PlcUInt32ArrayType, PlcName, UInt32[])

Initializes a new instance of the [PlcUInt32Array](#) class using the specified [type](#), [name](#) and [values](#).

C#

```
public PlcUInt32Array(PlcUInt32ArrayType type, PlcName name, params uint[] values)
```

Parameters

type [PlcUInt32ArrayType](#)

The [PlcUInt32ArrayType](#) of the new [PlcUInt32Array](#) to which the PLC array belongs.

name [PlcName](#)

The name of the array represented.

values [UInt32\[\]](#)

The initial values of the new [PlcUInt32Array](#).

Exceptions

[ArgumentNullException](#)

The **type** or **name** is a null reference (Nothing in Visual Basic).

PlcUInt32Array(PlcUInt32ArrayType, UInt32[])

Initializes a new instance of the [PlcUInt32Array](#) class using the specified **type** and **values**.

C#

```
public PlcUInt32Array(PlcUInt32ArrayType type, params uint[] values)
```

Parameters

type [PlcUInt32ArrayType](#)

The [PlcUInt32ArrayType](#) of the new [PlcUInt32Array](#) to which the PLC array belongs.

values [UInt32\[\]](#)

The initial values of the new [PlcUInt32Array](#).

Exceptions

[ArgumentNullException](#)

The **type** is a null reference (Nothing in Visual Basic).

Methods

GetElementCore(Int32)

Retrieves the [PlcUInt32](#) at the specified index.

C#

```
protected override PlcUInt32 GetElementCore(int index)
```

Parameters

index [Int32](#)

The zero-based index of the element to get.

Returns

[PlcUInt32](#)

The [PlcUInt32](#) at the specified index.

GetValueCore(PlcDeviceConnection)

Retrieves the current value of the PLC value from a [IPlcDevice](#) using the **connection** specified.

C#

```
protected override uint[] GetValueCore(PlcDeviceConnection connection)
```

Parameters

connection [PlcDeviceConnection](#)

The [PlcDeviceConnection](#) from that the data is to be retrieved.

Returns

[UInt32\[\]](#)

The current value of the PLC value.

Exceptions

[InvalidOperationException](#)

The **connection** is in [Faulted](#) state and cannot longer be opened.

[ObjectDisposedException](#)

The **connection** has been disposed of.

RelocateCore(PlcAddress)

Relocates the value to the **address** specified.

C#

```
protected override IPlcValue RelocateCore(PlcAddress address)
```

Parameters

address PlcAddress

The **PlcAddress** to that the value is to be relocated.

Returns

IPlcValue

A new instance of the same type as this PLC value instance relocated to the **address** specified.

SetValueCore(PlcDeviceConnection, UInt32[])

Stores the **value** in the **IPlcDevice** assigned to the **connection** specified.

C#

```
protected override void SetValueCore(PlcDeviceConnection connection, uint[] value)
```

Parameters

connection PlcDeviceConnection

The **PlcDeviceConnection** to use to store the **value**.

value UInt32[]

The value to be stored.

Exceptions

InvalidOperationException

The **connection** is in **Faulted** state and cannot longer be opened.

ObjectDisposedException

The **connection** has been disposed of.

Table of Contents

| | |
|---|---|
| Constructors | 1 |
| PlcUInt32Array(PlcIdentity, Int32) | 1 |
| PlcUInt32Array(PlcIdentity, PlcName, Int32) | 1 |
| PlcUInt32Array(PlcIdentity, PlcName, UInt32[]) | 2 |
| PlcUInt32Array(PlcIdentity, UInt32[]) | 3 |
| PlcUInt32Array(PlcUInt32ArrayType) | 3 |
| PlcUInt32Array(PlcUInt32ArrayType, PlcName, UInt32[]) | 3 |
| PlcUInt32Array(PlcUInt32ArrayType, UInt32[]) | 4 |
| Methods | 4 |
| GetElementCore(Int32) | 4 |
| GetValueCore(PlcDeviceConnection) | 5 |
| RelocateCore(PlcAddress) | 5 |
| SetValueCore(PlcDeviceConnection, UInt32[]) | 6 |

